AMV-1606-080531 V1.0



Technical Manual (:ANAPURNA MV)



Content

1. How to Install 3
2. Exterior Appearance & Specification 15
3. How to Use & List of Notice in Use27
 Error in Output & Quality of Printing 94
5. Servo Motor Driver 98
6. Electric Diagram / PCB Description 122

MODEL : ANAPURNA MV

1.How to Install



How to Install I-1

The below is important information that should be checked during installation.

- 1. The recommended work space for printing is 5M*5M. (Actual Machine size => 3.5M*1.52M*1.6M)
- The room in which the printer shall be installed should be easy to clean, dust-free space, Electromagnetic-free space. Reasonable temperature in 68 ~ 85°F(20~29°C) should be kept. Humidity in 20%~80% as well.
 - * Requirement for installation

Temperature	68°F to 85°F (20℃ to 29℃)	
Humidity	20% to 80% Non-condensing	

- 3. This equipment should be installed on horizontal surface in order to get the printing in the best quality.
- 4. The equipment should be run with single grounding.
- 5. In case the safety of working space is required, gas ventilation system will be asked, and the exhaust duct and ventilation fan should be installed

How to Install I-2

- 1. Dismantle the front and the upper of WOODEN BOX. (Remove the screw on the Front and Upper with a driver or electric tool.)
- 2. After dismantling the packing box, the equipment is relocated by Folk Lifter.

***** List of Notice in relocating the printer.

- As shown in below, the equipment should be lifted up at the marked position.
- When forks of lifter are inserted, be aware not to damage (scratch) the equipment !!
- After checking the left & right balance of equipment, the equipment should be lifted up slowly.
 (Please attention that it is sensitive device for impact.)
- Please check a relocating route before carrying by Lifter.

How to Install I-2



How to Install II

3. After relocating to desire place, should make a machine balance by using high & low controlling bolts and level checker.

The position of level checker should be based on box beam, connecting bar and side panel (left, right).

4. ANAPURNA MV is a device that needs compressed air.

Air line connected to Air-compressor or installation place should be mounted on right side of equipment.

- -The diameter of Air Inlet Tube is $\Phi 6$.
- -The pressure of Compressor is 4~8kgf /cm², Capacity of above 2HP. (640 kcal/hr,760W) Air production is over 6 LPM.
- ★ The Compressor must be Oil-less product.
- ★ It is recommended that the compressor should be run independently.
- 5. Besides the standard power grounding, the print in good quality can be obtained by connecting grounding line to controller panel in the middle of Machine rear side.

How to Install III

6. After connecting with AC-Line and grounding, connect with machine power code (220V \pm 10%, Grounding : Less than 5V)

- : ANAPURNA MV consists of power part of main body and that of sub-body.
- 1 st circuit breaker (main S/W) : ON / OFF for power source of main body.
- 2 nd Circuit breaker (main breaker S/W) : ON / OFF for Main Power.
- 3 rd START S/W

: Operation of printer.



After printer installation, please supply the ink in accordance with How To Install IV. In case of not following the procedure or skip, some problems related to head block & printing error would happen.

In order for personnel protection in operation of printing, must understand the printer by studying thoroughly working guide described in the MSDS.

*APPENDIX: MSDS attached.

How to Install IV-1 (HEAD CLEANING & INK SYPPLY)

STEP 1. After removing the cap of ink tube in refill connecting part, push the solution which remains in ink tube into sub ink tank by using tubing pump including filter.



Be careful that a solution should not be smeared on the printer while carrying out solution or ink handing work.

If smeared on the printer, its surface will be discolored.

STEP 2. Connect ink supplying tube in refill system with tube connector of printer.



Make sure that the ink tube and connector of printer are tightly connected by the NUT in end of supplying tube. Impact can cause of tubing-out problem.

How to Install IV-2 (HEAD CLEANING & INK SUPPLY)

STEP 3. Fill 500ml of ink in a main refill ink tank.

- → Be sure to deflate the air from ink filter of refill part and fill with the ink after being finished automated refill.
- → If ink is supplied in the condition that the air in Ink filter is not completely removed, overflowing from secondary ink tank will take place due to excess of air quantity.



Structure of Sub Ink Tank

How to Install IV-3 (HEAD CLEANING & INK SUPPLY)

STEP 4. Check the status of printer by turning ON S/W of 1st and 2nd circuit breaker.





S/W of 2nd Circuit Breaker

How to Install IV-4 (HEAD CLEANING & INK SUPPLY)

- STEP 5. (1) When powered on firstly, the headbase will be in very high position for HOME CHECKING by lifting up headbase.
 - (2) After being sucked and fixed by putting a Media on and turn on VACUUM, then press CALIB. Key.
 - (3) By selecting F6 HEAD GAP, the height of head can be set less than 2mm from Media.

(The closer the head is set to the media, the better the quality will be)

- \rightarrow When completing the adjustment of head height, move carriage to HOME Position.
- STEP 6. Solution cleaning
 - 1) Make the 6 mini values turn to S direction.
 - 2) Also make solution valve turn to S direction.
 - 3) Discharge the solution toward the head by pressing purge button.



How to Install IV-5 (HEAD CLEANING & INK SUPPLY)

STEP 7. Make ink supply to the head after supplying the ink in refill system to sub-ink tank. (Before auto refill, make ink 50cc discharge through head.)

→ Supply the ink in sub ink tank to the head by pressing purging S/W twice for 3 ~ 4 sec located in the upper right in Carriage rear side, then check the ink dropping in HEAD Nozzle.

- → If ink dropping takes place in the Head Nozzle, set the value of pressure to between -0.028 ~ -0.038 by turning Knob of Pressure Control to UP direction (right). (Standard Pressure is normally measured in the condition of no ink dropping from Nozzle. The unit is Kg/cm².)
- → The surface of each head is cleaned two or three times with Head Cleaner. Or use the best cleaner for Konica Head to clean.
- → Move the Carriage to HOME Position by pressing ESC key in the control panel, then with F1 PRIME, check the status of Head Nozzle.
- * If the Nozzle is in imperfect condition, check the status of Head Nozzle by repeating STEP 7 in order.

How to Install IV-6 (HEAD CLEANING & INK SUPPLY)

STEP 8. After checking machine setting, make RTL FILE from image file for printing.

- \rightarrow Create a desire image in RTL FILL by using RIP PROGRAM.
- \rightarrow Print out RPL FILE in RIP Program.
- * Check the trouble shooting if there is any trouble in the quality of printing.

MODEL : : ANAPURNA MV

2. Exterior Appearance & Specification



:ANAPURNA MV FRONT VIEW



Exterior Size (3,500mm*1,520mm*1,600mm) MAX PRINT WIDTH: 1,597mm

:ANAPURNA MV FEATURE



- □ Size (3,500mm*1,520mm*1,600mm) Max Print : 1.597mm
- UV Lamp Shutter System in accordance with printing signal.
- □ Auto lifting System : Max Media : 50mm
- □ High Resolution in Printing : KONICA HEAD INSTALLED (KM512 / 14PL)
- □ Stable Ink Supplying System
- □ Ink Jetting Control by Voltage Controller in Head Jet
- □ Auto Heating Device / Auto Ink Supplying Device / Auto Media Feeding Device
 - / Auto Suction System / Auto Capping System
- □ Flat Bed / Roll to Roll Hybrid Printer

:ANAPURNA MV SPECIFICATION

Model	:ANAPL	JRNA MV	
Printing Technology	DOD PIEZO ELECTRIC TECHNOLOGY		
Number of Print Head	6 HEADS [KONICA / 512 / 14PL]		
Print Speed	NORMAL MODE	QUALITY MODE	
	13-17 sqm/hr	6-10 sqm/hr	
CPU	32BIT RISC		
Memory	256MB		
Command Language	SP-RTL, HP-RTL, EMULATION		
Interface	TCP / IP		
Ink Type	UV BASED PIGMENT		
Dimensions [W X D X H]	3,500 X 1,520 X 1,600 (mm)		
Weight	ABOUT 620 KG		
Max Printing Width	1,600 mm		
Input Voltage	SINGLE PHASE 220V \pm 10 % [50/60Hz, AC]		
Media Thickness	50mm		
Media Type	HYBRID TYPE [FLATBED & ROLL TO ROLL]		
Motor Type	CARRIAGE : AC SERVO MOTOR	/ FEED : AC SERVO MOTOR	

:ANAPURNA MV BLOCK DIAGRAM



19

INK SUPPLY FLOW DIAGRAM



CODE STRIP



The Print Resolution was improved by CODE STRIP (180 dpi).

STRUCTURE OF BOX BEAM



Easy Moving Carriage Structure in Box Beam (LM GUIDE 2EA USE)

STRUCTURE OF PLATEN



Designed for easily using the Plate. (Origin Point Fix Air Cylinder attached)

STRUCTURE OF FRONT ROLL BAR



ROLL BAR IN FRONT MEDIA

STRUCTURE OF REAL ROLL BAR



The tension of media should be maintained equally with the roll bar in the rear.

STRUCTURE of CONTROL BOX



The PCB assembled with three SUB PCBs was designed for easy to attach and detach.

MODEL : : ANAPURNA MV

3. How to Use and List of Notice in Use



- 1. Keep the horizontality : Required for accurate printing
 - → Should be checked during the first installation in order to keep the printer in stable condition.
- Maintain the grounding : Required for stable system maintenance.
 → Should be checked during the first installation in order to keep the printer in stable system.
- Code Strip → Once a week, need to be cleaned with head cleaner to secure stable printing.

- 4. Check the Terminal of UV LAMP POWER.
- → Check voltage/frequency(230V/60Hz)
 A-1(203V/50Hz), A-2(203V/60Hz)
 B-1(230V/50Hz), B-2(230V/60Hz)



- 5. Check the sensor sensitivity of MAIN TANK.
- \rightarrow When ink is short, BUZZER beeps.



- 6. Check INK FILTER
- → After filling the ink into MAIN INK TANK, deflate the air in the filter.



- 7. Check INK SUPPLYING HOSE
- → Check ink supplying hose for each color.



- 8. Check the sensor in Waste Ink Tank
- → The message of Waste Full (purge) will be displayed on the LCD, and also check the Buzzer.
- 9. Check the SOLUTION TANK
- → Check amount of solution in the tank of MAIN/SUB SOLUTION.







- 10. Check the voltage of CARRIAGE PCB.
- → Check accurate setting of voltage at each head.



- 11. Check the pressure in air tank.
- → Check the pressure of 4 ~6 kgf/cm² in Air Tank.



- 12. Check the Parameter of SERVO MOTOR DRIVER.
- → Check the value of FEED/CARRIAGE SERVO MOTOR DRIVER.

- 13. Check the Temperature controller.
- → Check the Temperature of SUB INK TANK(45C), HEADBASE(49C) & VANISH (40C).



- 14. Beware of accurate ink supply for each color and ink spilling.
 - → Make sure not to confuse Magenta with Light Magenta, and Cyan with Light Cyan.
 - → Also please make sure SOLUTION and VANISH INK not to mix to use.
 - → If the ink is spilled on the surface of machine, first clean with a small amount of solution, and then clean again with alcohol.

Alignment

There are three ways for Alignment.

- Head Alignment
- Head Base Alignment
- Lamp House Alignment

Head Alignment

- 1) Control right & left slope of print head
- 2) Control up & down alignment of print head
- 3) Use two adjusting bolts and two fixing bolts.

There are M3 bolt and fix bolt on both front side and back side.



Alignment

2) Alignment of Head Base

- 1) Control right & left alignment of head base.
- 2) Control front & rear alignment of head base.
- 3) Use two adjustment blocks.



There is an adjustment **block in the left and right side.**


Alignment

3) Alignment of Lamp House

1) Control device for left, right alignment of Lamp House.

2) Use two adjusting bolts for the left, right control.

Adjustment bolt in the Right & Left



ABSOLUTELY KEEPING

- 1. Vacuum pressure checking: If the power of printer is on, the supply of compressed air should be available. (The value required for controlling each part should be aligned within the values written in the Sticker mentioned on each part.)
- 2. While the printer is not in use, clean the head and install the capping device.
 - \rightarrow Protect the head by cleaning head solution. (once or more a day)
 - → If machine is on, if print in operation more than 1 hr and if run for 20 m²/h, the pursing process will help the head nozzle to protect.
 - → If power is off in operating, the solution must be filled in within a short time in order to protect the Head.
 - \rightarrow If power is OFF, should do capping after cleaning the head solution.
- 3. Before turning on the power of printer, should check ON status of COMPRESSOR and then turn on the power. On the contrary, when the power of printer is turned off, after cleaning the head and completing the capping, then turn off the power of COMPRESSOR.

LIST OF NOTICE WHEN TURNING THE POWER ON

1. Dismantle all the power cables. (Shut down the Main Breaker.)

- 2. Verify the voltage short after dismantling all the cables.
- Tester is adjusted at the position of measuring the resistance. When measuring the power cable and grounding, must have O.L value (unlimited).
- 3. After short test, verify the chassis between AC LINE and MAIN BODY.
- 4. After shutting down all the breaker (C/B), turn on the S/W of main breaker (C/B).
- 5. Verify the status by turning ON/FF the S/W of each breaker.
- 6. Take out DC connector going to the Main and the Head.
- 7. Verify the status of printer by supplying power to each part. (Turn on head power, motor power and the power of main body in sequence.)
- 8. Verify whether the DC Power is normal or not by turning ON/OFF the power of controller.
- 9. Connect with DC connector going to the Main and the Head.
 - Verify the status of connecting, and also verify 24V of Main & Head PCB, GND, frame grounding.
- 10 Turn on all the breakers.
- 11. Check the status of printer after turning on the main power.

ENCODER & CODE STRIP CHECK

- 1. Verify the status of red light on the encoder after turning the powder on.
- 2. If CALIB. key is pressed down right after pressing down F2 Carriage Release, the carriage can be relocated by hand.
 - When you push the carriage forward, check whether Code Strip is stuck or bent while the encoder is passing thru code strip.
 - The incorrect assembly can cause an jetting problem in printing or abnormal output. Must verify correctness of the height & angle of encoder.
- 3. Wipe away dust, water, oil etc on the Code Strip with clean cloth or flannelette.
- For cleaning, do not use acetone, benzene, solvent or thinner because they can erase the graduations printed on code strip.
- 4. If there is nothing wrong, F1 SERVO ON and HOME CHECK is pressed down. Then the Carriage will be servo-on and check the Home.
- 5. In case the Code Strip needs to be changed due to serious scratch and contamination, should check it by A/S engineer by contacting **AGFA**.
- 6. When it is changed, verify whether the Code Strip is in 180 dpi or not.

*Cautions

Since the Code Strip is sensitive to shock, please be careful not to put any stuff on it and to touch, and keep it clean. Manage It carefully.

NEGATIVE PRESSURE CHECK

1. Verify the operational condition of air compressor.

- 2. Verify the gauge of vacuum pressure.
- Set the pressure value as written on the sticker.
- If you got any trouble on vacuum pressure, it can cause series trouble for printing as falling-off of nozzle and ink dropping.
- 3. Remove the water in the filter when the water level reaches upto 1/2 in the filter of panel of compressor.
 - Be cautious that the water should keep away from electric part.
- 4. Remove waste ink that was supplied from sub ink tank.
- 5. Should remove the water by opening the drain valve of air tank at least every other day.

*Cautions

If nothing is changed even if the pressure in the regulator is changed, should check the hose linking with setting valve and regulator.

ASSENBLY & DISASSEMBLY OF CONVEYOR BELT



1) Separate the valve after removing the pin linking between belts.



② Connect the belts by inserting a pin between them.(Two persons needs for this work.)



③ Insert the pin to the end. the remain section is fold and then insert into the belt.

Designed for easy assembly and disassembly of the Conveyor Belt.

TREE MENU-1



TREE MENU-2



TREE MENU-3



CONTROL PANEL-1



CONTROL PANEL-2

- ON LINE Key : Used to change the status of OFF LINE to that of ON LINE.
- ON LINE Indicator : Light is on in ON-LINE MODE, if OFF, will shut down after showing up the data of print shortly.
- ESC Key : Use it when function is cancelled.
- 4 F1 Key : Perform Function 1.
- **5** F2 Key : Perform Function 2.
- **6** F3 Key : Perform Function 3.
- **F4** Key : Perform Function 4.
- **B** F5 Key : Perform Function 5.
- 9 F6 Key : Perform Function 6.
- **1D** TEST Key : Key accessed for TEST Menu.
- CALIB. Key : Key accessed for CALIBRATION Menu.
- **12** PURGE Key : key accessed for PURGE Menu. Move Carriage to PURGE side.
- **(13)** CAPPING Key : Key accessed for CAPPING Menu.
- **1** PAUSE Key : Key for Temporary Function Stop.
- **(15)** ENTER Key : Key for Function Performance & Various Parameter Saving.
- **UP Key : Key for Value up when entering Parameter.**
- **DOWN** Key : Key for Value down when entering Parameter.
- LEFT Key : Key for moving Article to right when entering Parameter, Key for moving Carriage to left when doing Gap Test.
- **RIGHT** Key : Key for moving article to left when inputt Parameter,

Key for moving carriage to right when performing Gap Test.

CO LCD DISPLAY : Display on-going & current status information.

DECRIPTION OF OFF-LINE MENU (MAIN)

:AN/	APURNA M	AG	FA 🐢
ON-LINE	OFF]	ESC
F1			F4
F2	HOST *** ***P S7 159 F1>PRIME F2>UV LAMP/SHUTTEF F3>HOME COVER	7mm tcp [K C M Y IC IM] CLEANING/IP SET <f4 ₹ TAKE UP<f5 PARAMETER<f6< td=""><td>F5</td></f6<></f5 </f4 	F5
F3			F6
TEST	CALIB.		SELECT
PURGE	CAPPING PAUS	E ENTER	BUTTON

Operation of Each Function Key

F1> PRIME: The function of PRIME is to check status of Nozzle Jetting and to get print-out in a decent quality
F2>UV LAMP SHUTTER : In printing, set ON/OFF of LAMP, Mode of shutter (standard, 2 at a time), Delay distance of Lamp Shutter, Lamp Off Time. Display Using Time for left or right Lamp.
F3> HOME COVER : If once, open and if press once again, close.
F4> CLEANING/IP SET: Use it when setting nozzle test and cleaning parameter. Should enter IP Address.
F5> TAKE UP : Set the mode by operating the TAKE UP MOTOR manually.
F6> PARAMETER: Use it when setting Printer parameter.

SCRIPTION OF OFF-LINE MENU (UV LAMP/SHUTTER

:ANA	PURN	AM		AGFA	Agro
ON-LINE	[OFF			ESC
F1	== U'	V LAMP/SHUTT	ER ==		F4
F2	UV LAMP:MOL SHUTTER: MC LAMP USE HO	DE = ON OFF I DE = NORMAL UR:LEFT= 9.4	IME (Min)=20 DELAY (ON/0 RIGHT= 28	OFF=) 30/30 3.7	F5
F3		- 1			F6
TEST	CALIB.			4	+ SELECT BUTTON
PURGE	CAPPING	PAUSE	ENTER	/	V

Operation of Each Function Key

UP Key ,DOWN Key : Value Change LEFT Key ,RIGHT Key : Movement of Article ENTER Key : Terminate after saving. ESC Key : Terminate without saving. UV LAMP:MODE = ON, OFF : ON, OFF of Lamp Mode OFF TIME (Min)=0~99 : OFF TIME of LAMP is 0Min ~ 99Min. SHUTTER MODE = NORMAL, BOTH : Shutter mode : Normal, turned ON at the same time

DELAY(ON/OFF) 0~99 : Position of Shutter Open/Close – 0~99CM LAMP USE HOUR: LEFT:9.4

> USE HOUR OF LEFT LAMP 9.4HR=9Hr 24Min RIGHT:28.7 USE HOUR OF RIGHT LAMP 28.7HR

=28Hr 42Min

USE HOUR of LAMP can be initialized only by engineer when the Lamp is changed.

ESCRIPTION OF OFF-LINE MENU (UV LAMP/SHUTTER)



Operation of each function key

Delete : If entering 6142513 in the UV LAMP/SHUTTER MODE, the LCD window like left will be displayed.
F1> LEFT : Delete accumulated Use Time Of Left Lamp.
F2> ALL : Delete accumulated Use Time of Both Lamp.
F4> RIGHT : Delete accumulated Use Time of Right Lamp.

After deleting Accumulated Use Time of Lamp, returned to MAIN MENU.

ESCRIPTION OF OFF-LINE MENU (CLEANING / IP SET)

:ANA	PURNA M	AGFA	4910
CIN-LINE E1	OFF	1	ESC
F2 F3	== CLEANINIG F1> HOME COVER F2> SAFETY SENSOR F3> FIRMWARE VERSION	/IP SET == IP SET <f4 NOZZLE TEST <f5 PARAMETER <f6< td=""><td>F5 F6</td></f6<></f5 </f4 	F5 F6
TEST	CALIB. CAPPING PAUSE	ENTER	SELECT BUTTON

Operation of each function key

- F1> HOME COVER : If pressing once, open. Then if pressing again, close F2> SAFETX SENSOR : Decide whether use of safety sensor
- F2> SAFETY SENSOR : Decide whether use of safety sensor or not.
- F3> FIRMWARE VERSION : After showing current firmware version for 3 sec, It will return to the previous mode, the mode of CLEANING/IP SET.
- F4> IP SET : Enter IP address of printing. (for example 192.168.1.5)
- F5> NOZZLE TEST : If possible to check jetting of each color, if is also possible to check the jetting of all the colors simultaneously.
- F6> PARAMETER : Possible to select whether use or not of capping motor, section time and operation time of solution capping motor.

SCRIPTION OF OFF-LINE MENU (CLEANING / IP SET)



Operation of each function key

UP Key ,DOWN Key : Value Change. ENTER Key : Terminate after saving. ESC Key : Terminate without saving. SAFETY SENSOR = ON, OFF : ON. OFF of USER MODE OF SAFETY SENSOR.

DESCRIPTION OFF-LINE MENU (CLEANING / IP SET) - 3



After showing up the current firmware version for 3 second. It will return to SET MENU OF CLEANING/IP, previous mode.

SCRIPTION OF OFF-LINE MENU (CLEANING / IP SET)



Operation of each function key

UP Key ,DOWN Key : Value Change. LEFT Key ,RIGHT Key : Shift of item. ENTER Key : Terminate after saving. ESC Key : Terminate without saving.

ECRIPTION OF OFF-LINE MENU (CLEANING / IP SET)) -

:AN	APURN	MAI	AGF	A Agro
CIN-LINE F1		OFF	1	ESC F4
		== NOZZLE TE	EST == MAGENTA <e4< th=""><th></th></e4<>	
F2	F2> CYAN F3> L_CYAN	ALLSLITIC	YELLOW <f5 L_MAGENTA <f6< th=""><th>F5</th></f6<></f5 	F 5
F3				F6
TEST	CALIB.			SELECT
PURGE	CAPPING	PAUSE	ENTER	BUTTON

Operation of each function key

F1> BLACK : Jetting all the nozzles of black head.
F2> CYAN : Jetting all the nozzles of CYAN head.
F3> L_CYAN : Jetting all the nozzles of Light CYAN head.
F4> MAGENTA : Jetting all the nozzles of Magenta head
F5> YELLOW : Jetting all the nozzles of Yellow head
F6> L_MAGENTA : Jetting all the nozzles of Light Magenta head

ENTER> ALL : Jetting all the nozzles of all heads. ESC> Use it when terminating Nozzle Jetting. (Will return to CLEANING /IP SET MENU, previous mode.)

• After jetting for 3 sec nozzle jetting, it will return to the screen like above.

)ESCRIPTION OF OFF-LINE MENU (CLEANING / IP SET)



Operation of each function key

UP Key ,DOWN Key : Value change. LEFT Key ,RIGHT Key : Shift of item. ENTER Key : Terminate after saving. ESC Key : Terminate without saving. CAPPING = ON, OFF : ON, OFF of CAPPING MOTOR SUCTION TIME (Sec)=OFF,1~20 : SUCTION OPERATION TIME, OFF for 1 sec upto 20 sec SOLUTION(CAP.) PUMP(Sec)= OFF,1~20 : Operation Time of Solution Capping Motor OFF for 1 sec upto 20 sec

DESCRIPTION OF OFF-LINE MENU (TAKE UP)



Operation of each function key

UP Key ,DOWN Key : Value Change.
LEFT Key ,RIGHT Key : Shift of Item.
ENTER Key : Terminate after saving.
ESC Key : Terminate without saving.
MODE = AUT, MAN : AUTO, MANUAL OF TASKUP MODE.
DIRECTION = CW, CCW : When in Auto Mode, rotation direction of front motor. CW: Clockwise, CCW: Counter Clockwise
F2> FRONT CW : Only for the time in pressing down, the front motor will be rotated In clockwise.
F3> FRONT CCW : Only for the time in pressing down, the front

- F3> FRONT CCW : Only for the time in pressing down, the front motor will be rotated in counter clockwise.
- F5> REAR CW : Only for the time in pressing down, the rear motor will be rotated In clockwise.
- F6> REAR CCW : Only for the time in pressing down, the rear motor will be rotated in counter clockwise.

DESCRIPTION OF OFF-LINE MENU (PARAMETER)



Operation of each function key

UP Key ,DOWN Key : Value Change, LEFT Key ,RIGHT Key : Shift of item ENTER Key : Terminate after saving.

ESC Key : Terminate without saving.
CONTROL = HOST, LOCAL Print Control Mode HOST: Host Setting Control LOCAL: Local Setting Control DIRECTION = UNI,BI Printing direction UNI: UNI-Direction Printing. BI: Bi-Direction Printing.
PASS=N1, N2, N4, Q2, Q4, Q8, F1, F2, F4 : A number of Pass in printing.
N1: 360 X 360 dpi N2: 360 X 720 dpi N4: 360 X 1440 dpi Q2: 720 X 360 dpi Q4: 720 X 720 dpi Q8: 720 X 1440 dpi F1: 720 X 360 dpi F2: 720 X 720 dpi F4: 720 X 1440 dpi Printing in the above modes.

C-SPEED= 1 upto 10 (standard 7) : Speed of Carriage F-SPEED=1 upto 5 (Standard 1) : Speed of feed UNIT=MM,INCH Unit : Inch, MM

WEEP=OFF,1~99 Weeping Time : OFF, 1 Sec upto 99 MARGIN (L=0~999 : Margin of Left : 0 ~ 999 MM N-POINT: Y,N :Use N-Point (Use, not use) T=0~999 : Upper Margin : 0 ~ 999 MM R=0~999 : Lamp Shift Margin : 0 ~ 999 MM F1> LOAD : Possible to load the parameter upto 10. F4> SAVE : Possible to save the parameter upto 10.

DESCRIPTION OF TEST MENU - 1



Operation of each function key

F1 => PRIME: The function of PRIME is to lead the printing in good quality by checking whether the jetting of Nozzle is normal or not.

- F2 => PRIME 2(N,Q) : Print the PRIME Pattern of 360dpi in length Resolution.
- F3 => PRIME 2(F) : Print PRIME pattern in 720dpi of length Resolution.
- F4 => BELT TEST : Use it when controlling tension of conveyor belt by rotating.
- F5 => DIR TEST(N,Q) : Print Bi-direction pattern in 320dpi of length resolution.

F6 => DIR TEST(F) : Print bi-direction pattern in 720 dpi of length resolution.

DESCRIPTION OF TEST MENU – 2



Operation of each function key

F1 => RUN : The conveyor belt is rotated forward.F4 =>STOP : Use it when stopping the rotation of conveyor.

- * The conveyor belt keeps rotated until pressing STOP.
- * Must press down ESC after pressing STOP <F4
- * Otherwise, even if pressing down ESC, the belt will keep rotating.



Operation of each function key

- F1 => FEED ADJUST : Use it when checking or changing current feeding value.
- F2 => CARRIAGE RELEASE : Able to move the carriage by hand after servo-off.
- F3 => FACTORY SETTING : USERS should not be changed after factory setting.

The incorrect setting can cause serious damage to the printer. (It is the mode that can be accessed after entering password.)

- F4 => HORI. ADJUST : Use it when checking or changing the Horizontal Adjustment of the Head.
- F5 => DIR. ADJUST : Use it when checking and changing the direction value in Bi-direction printing.
- F6 => HEAD GAP : Use it when setting the gap between the Media and the Head.



Operation of each function key

- UP Key ,DOWN Key : Value Change
- ENTER Key : Terminate after saving
- ESC Key : Terminate without saving
- F2> PRINT : Print feeding pattern set in current feeding value.
- * The range of setting value is -50 upto 50.
 - If increasing setting value, the image will be wider.
 - If decreasing, the image will overlap.
- * If setting with correct feeding value, will be able to get the print in a good quality.



Operation of each function key

F1> SERVO ON And HOME CHECK :

After Carriage is servo-on, do the HOME CHECK Then the carriage will be moved without changing the height of headbase, be cautious while in motion.

:ANA	PURNA M	AGFA
ON-LINE	OFF	ESC
F1 F2	== CALIBRATION ==	F4
F3		F6
TEST	CALIB.	SELECT
PURGE	CAPPING PAUSE ENTER	BUTTON

Operation of each function key

Enter two different passwords in the entrance space of password

First password is to access SYSTEM OPTION/TEST MENU. (PASSWORD: INPUT)

The other password is to access FACTORY SETTING MENU.

(PASSWORD : 164325)

:ANA	APURNA M	AGF	A Agro
CIN-LINE	OFF		ESC
F1			F4
	== SYSTEM O	PTION / TEST == SYSTEM OPTION < E4	
F2	F2> DIR PRINT (N,Q)	HEAD TEMP/VOLT <f5< th=""><th>F5</th></f5<>	F5
F3			F6
		- 2	
TEST	CA RIB.	- 1	
PURGE	CAPPING PAUSE	ENTER	BUTTON

Operation of each function key

F1> HORI. PRINT : Print the horizontal adjustment pattern in full size.
F2> DIR PRINT(N,Q) : Print bi-direction pattern in 360dpi of horizontal resolution.
F4> SYSTEM OPTION : Setting whether or not the use of HOME COVER while factory setting.
F5> HEAD TEMP/VOLT : Use it when checking status of voltage and temperature of current head.

:AN	APURNA M	AGFA 🛷
CIN-LINE F1	OFF	ESC 3
	== SYSTEM OP	TION ==
F2	HOME COVER = ON	F5
F6		F6
		2
TEST	CALIB.	1
PURGE	CAPPING PAUSE	ENTER

Operation of each function key

UP Key ,DOWN Key : Value Change ENTER Key : Terminate after saving ESC Key : Terminate without saving HOME COVER = ON,OFF : If HOME COVER is air cylinder type, and only if sensor is attached, set ON. If HOME COVER is manual type, and if there is not sensor, set OFF.

* HOME COVER will either be opened or not be closed if OFF Setting. Please make sure it.



Impossible to change if marking in here.

Temp : Display current temperature of each head.

- LEFT: The currently permitted voltage is displayed in the left column of each head
- RIGHT: The currently permitted voltage is displayed In the right column of each head.

:ANA	APURNA M	AGF	A 400
CIN-LINE	OFF		ESC
F1			F4
F2	== FACTORY S F1> HEAD ADJUST SY F2> HEAD VOLT. SETTING F3> HEAD VOLT. CALIB.	SETTING == STEM REFERENCE <f4 TEMP/VOLT <f5< td=""><td>F5</td></f5<></f4 	F5
F3			F6
		2	
TEST	CALIB.	1	SELECT
PURGE	CAPPING PAUSE	ENTER	BUTTON

If entering password (1643259) that can access to FACTORY SETTING MODE, the contents like shown in the left LCD screen will be displayed.

Operation of each function key

- F1> HEAD ADJUST : It is the mode for adjusting HEAD ALIGMENT ANGLE.
- F2> HEAD VOLT. SETTING : Set HEAD VOLTAGE.
- F3> HEAD VOLT. CALIB. : It is the mode for adjusting REFERENCE VOLTAGE of CARTRIDGE PCB.
- F4> SYSTEM REFERENCE : It is the mode to set reference value of head cap and setting value of printing point and N-point.
- F5> TEMP/VOLT : Use it when checking Temperature of current head and Permitted voltage status.



Operation of each function key

F1> PRINT: Print the pattern of HEAD ALIGNMENT ANGLE.

F5> ADJUST END: Use it when ending HEAD ALINMENT.

ESC: Use it when ending HEAD ALIGNMENT.



Operation of each function key

UP Key, DOWN Key : Value Change LEFT Key, RIGHT Key : Shift of time ENTER Key : Terminate after saving ESC Key : Terminate without saving

* After checking the label stuck on the head, Set the voltage that is higher than 3.2V.

:AN	APURNA M	AGFA
• • CIN-LINE	OFF	ESC
F1	== Head Voltage Calib	ration ==
F2	High Voltage (TP1,TP4) 15.00V Low Voltage (TP2,TP5) 7.50V	F5 F6
TEST	CALIB.	,3 1
PURGE	CAPPING PAUSE EN	NTER

It is the mode for adjusting REFERENCE VOLTAGE of CARRIGE PCB.

Matching the LOW and HIGH of standard voltage in the left and right channel to 15V and 7.5V by changing variable resistance.

\rightarrow Entered	d into setting	g Mode of v	oltage.		
High Vo	ltage(TP1,1	(P4) 15.00			
Low Vo	ltage(TP2,	TP5) 7.50V			
LH; The	e voltage in	TP1 is set t	o 15.00V by	rotating VR	1.
LL;The	LL; The voltage in TP2 is set to 7.50V by rotating VR2.				
LH; The	LH; The voltage in TP4 is set to 15.00V by rotating VR3.				
LL;The	e voltage in	TP5 is set to	o 7.50V by i	rotating VR4.	1
2. After completing the setting, press ESC.					
\rightarrow changed to the Mode of SYSTEM OPTION/TEST.					



Operation of each function key

UP Key ,DOWN Key : Value Change LEFT Key ,RIGHT Key : Shift of item ENTER Key : Terminate after saving ESC Key : Terminate without saving

PRINT ORIGIN(mm) = -50 upto 50 : Decide position of printing 0 point
 NULL-POINT =-999 upto 999 : After feeding the media in the location of media setting.
 Use it when setting print start position.

If set value is +, feeding upward, If -. feeding downward. If setting 0mm, won't feed.

HEAD GAP REFERENCE = 2.0mm upto 10.0mm : When setting headcap and sensing the media by the media sensing bracket, it is the distance between media and headbase.

Based on this value, adjust the distance between media and headbase.


- It is impossible to change if making a mark in here.
- Temp : Display the current temperature of each head.
- LEFT: Display the permitted voltage in the left column of each head
- RIGHT: Display the permitted voltage in the right column of each head

:AN	APURNA M	AGFA
CN-LINE	OFF	2 Esc
F2	== HORIZONTAL CA F2> PRINT K1=0 C1=-1 M1=-3 Y1=-6 K2=0 C2=-1 M2=-3 Y2=-6	ALIBRATION == CLEAR <f5 6 LC1=-8 LM1=-5 6 LC2=-8 LM2=-5</f5
F3 TEST	CALIB.	1
PURGE	CAPPING PAUSE	ENTER

Operation of each function key

UP Key ,DOWN Key : Value Change ENTER Key : Terminate after saving ESC Key : Terminate without saving . F2> PRINT : Print feeding pattern set in current feeding value.

F5> CLEAR : Initialize all the data. (set to 0 for all the data)

* The range of setting value is -20 upto 20.

If set value is increased, the image will be wider to the right. If set value is decrease, the image will be wider to the left.

If setting horizontal alignment value correctly, can get the print in a good quality.

:ANA	PURNA M	A	GFA 🛷
ON-LINE F1	OFF	2	ESC F4
F2	== DIRECTION CAI F2> PRINT K1=0 C1=0 M1=0 Y1=0 K2=0 C2=0 M2=0 Y2=0	LIBRATION == CLEAR <f5 0 LC1=0 LM1=0 0 LC2=0 LM2=0</f5 	4 5
TEST	CALIB.	1	SELECT
PURGE	CAPPING PAUSE	ENTER	BUTTON

Operation of each function key

UP Key ,DOWN Key : Value Change ENTER Key : Terminate after saving ESC Key : Terminate without saving F2> PRINT : Print feeding pattern set in current feeding value. F4> MODE : N,Q mode and FINE mode will be displayed alternatively. F5> CLEAR : Initialize all the data.

(set to 0 for all the data)

* The range of setting value is -10 upto 10

If set value is increased, the image will be pushed to the left. If set value is decrease, the image will be pushed to the right. IF setting bi-direction alignment value correctly,

Can get the print in a good quality.

Only, when print out in uni-direction, won't apply for this value.



Operation of each function key

LEFT Key , RIGHT Key : The carriage is moved to left, right of HEAD MOVE. Move to left 10 times. UP Key , DOWN key : GAP Value Change

F6 => REFERENCE : It is the mode for setting the BRACKET REFERENCE VALUE sensing the media. (password : 164325) The value is 0.5mm uptp 10 mm. Up / down in the unit of 0.1mm.

ENTER : Move to next step.

If canceling all the procedure, the head will return to HOME POISTION.

Only, since the head base will keep the height set at the last procedure, please push down after double checking that there will not be any trouble even if returned to HOME.



Operation of each function key

LEFT Key, RIGHT Key: The carriage is moved to left, right of HEAD MOVE. Move to left 10 times.

UP Key , DOWN key : REFERENCE Value Change

F6 => RETURN : Return to HEAH GAP SETTING MODE.

The VALUE is 2.0mm upto 8.0mm. Up / down in the unit of 0.1mm.

ENTER : Move to next step.

ESC : If canceling all the procedure, the head will return to HOME POISTION.

Only, since the head base will keep the height set at the last procedure, please push down after double checking that there will not be any trouble even if returned to HOME.

:ANA	PURNA M	AGFA 🧄		
CIN-LINE	OFF		ESC	
F1			F4	
F2	== HEAD GAP Gap Set [1.8mm] ref [4.5] : Head Move: right/left Key NEXT: ENTER Key	SETTING == UP/DOWN Key REFERENCE <f6< td=""><td>F5</td></f6<>	F5	
F3			F	
		1 2		
TEST	CALIB.		SELECT	
PURGE	CAPPING PAUSE	ENTER	BUTTON	
			and the second second	

* Order of Operation *

Keep pressing down <-- until the head reaches to Top. And then move it to left. Press \leftarrow several times in order to move the carriage to the position in which you want to measure.

If pressing down the ENTER Key, L bracket is down, and the Head is also down with rotating stepping motor. It will stop when L bracket reach the ground.

Since this position is the height of reference. Set this height. (password : 164325) Then by pressing F6 Key, switch to HEAD GAP MODE. Set the height of media and head by pushing ENTER KEY.

<It is recommended to keep the height less than 2mm>

:AN	APURNA	M		AGFA	Agro
CN-LINE F1	(DFF			ESC F4
F2 F3	F1> CAPPING F2> SUCTION	== PURG	;E ==		F5 F6
TEST	CALIB.	PAUSE	ENTER		SELECT SUITTON

Operation of each function key

F1 : Run the head capping. F2 : Run the SUCTION.



Once the carriage reaches the highest position, the bracket in L type is moved down.

After the carriage is lowered and after the Bracket in L type senses the cover of capping, the bracket again is moved up.

After the carriage stops, the carriage again moves down to the capping pad and adhered closely. After that. By making capping pump run for a setting time, The function of filling in capping pad with cleaning solution is carried out.

With completeness of capping, the message in the LCD window will be displayed.

If the power is off or the capping wants to be cancelled in this status. press the ESC key.



Once the carriage reaches the highest position, the bracket in L type is moved down.

After the Bracket in L type senses the cover of capping, the bracket again is moved up.

After the carriage stops, the carriage again moves down to the capping pad and adhered closely. After that. By making capping pump run for a setting time, The function of filling out cleaning solution smeared on the capping pad and head is carried out. While the function of suction is performed, The message in the left LCD window will be displayed.

With completeness of suction, return to the PURGE Menu, previous mode.



Operation of each function key

- F1: Run the head capping.
- F2: Run the SUCTION.



It is the mode to adjust REFERENCE VOLTAGE OF CARRIGE PCB.

By changing the variable resistance, match Low & High Standard Voltage in the left and right channel to 15V and 7.5V

*PCB Voltage Adjustment <h w=""></h>						
1. Press Purge Key	→The Carrig	ge will be rele	ocated			
	to the posit	ion of purge.				
2. Press Carib Key	\rightarrow Entered i	into Calibratio	on Menu.			
3. Press F2>Head Volta	ge Calibratio	n				
→ Entered into Settir	ng Mode of V	Voltage.				
High Voltage(TP1,	TP4) 15.00	V				
Low Voltage(TP2,	TP5) 7.50V					
LH; The voltage in	TP1 is set t	o 15.00V by	rotating VR	1.		
LL; The voltage in	TP2 is set t	o 7.50V by	rotating VR2			
LH; The voltage in	TP4 is set t	o 15.00V by	[,] chaning VR	3.		
LL; The voltage in	TP5 is set t	o 7.50V by	rotating VR4			
4. After completing the s	setting, press	s ESC.				
\rightarrow Changed to mode	of Calibratio	n.				
5. Press ESC.	→ Chang	jed to the ma	ode of Purge			
6. Press ESC.	\rightarrow The ca	arrige will be	relocated to	the Home.		
			0			
			00			



Operation of each function key

UP Key, DOWN Key : Value Change LEFT Key, RIGHT Key : shift of item ENTER Key : Terminate after saving ESC Key : Terminate without saving

* Set the voltage higher than 3.2V by checking the label in Blue color attached on the head.

DESCRIPTON OF CAPPING MENU



After moving the carriage to purge direction. Carrying out the function of capping shortly.

If you want either to turn off the power or to cancel the capping,

Press down ESC key.

IMAGE PRINTING OUT (PRINT)

	:ANAPURNA M AG	FA doto
ON - PRESS -	CN-LINE F1 F2 HOST UNI Q4P S7 1597mm TCP [K C M Y IC IN F2 PRINTING 10 /100 (10%)	ESC F4 M] F5 F6
	TEST CALIB. PURGE CAPPING PAUSE ENTER	SELECT BUITON



- 1. Once pressing ON-LINE Button, transfer the image file to be output from RIP. (In the RIP program, in case of RIP AND PRINT, RIP will be also printed out.)
- 2. If START button in the RIP is pressed down, printing begins and printing image will be shown up in the LAP program.

86

CANCELLATION OF PRINTING



1. After pressing down ESC in the Keyboard, if selecting the ENTER button, the printing will be cancelled.

87

SELECT SWITCH-1

1. Lamp Control<Left, Right>



1)MODE: OFF, LO, HI 3
OFF: In the OFF position, can not turn Lamp on.
LO : In the LO position, Lamp work as LO.
HI : In the HI position, Lamp work as HI.
※ If there is no signal from UV LAMP even if Lamp select switch position in HI or LO, the LAMP won't be on.

2) If pressing down F2>UV LAMP/SHUTTER in the MENU of OFF-LINE, == UV LAMP/SHUTTER == UV LAMP:MODE = ON OFF TIME (Min)=20 SHUTTER: MODE = NORMAL DELAY (ON/OFF=) 30/30 LAMP USE HOUR:LEFT= 9.4 RIGHT= 28.7 Here, if UV LAMPMODE= ON, when doing all the prints including Prime and Calibration, print with Lamp on.

If OFF, then when printing out all the prints including Prime or Calibration, print with Lamp OFF.

The meaning of OFF-TIME (MIN)=30 is that UV LAMP will be OFF if next printing order is not entered within 30 min after finishing print.

SHUTTER MODE = NORMAL - Operation of Normal shutter (Operation of right shutter.) BOTH - two shutters will be operated at the same time. (right, left)

ex) In BI-DIRECTION printing

NORMAL : When printing out from HOME to PURGE, the right shutter will be opened, When printing out from PURGE to HOME, the left shutter will be closed.

BOTH : When printing out from HOME(right) to PURGE(left), two opened and closed at the same time. Again when printing out from PURGE(left) to HOME(right), two closed and opened at the same time.

In accordance with type and thickness of media the mode will be selected by adjusting amount of Light. LO will be selected for thin Acryl or film (soft material type) HI is selected for glass or tile.



SELECT SWITCH-2

 \Rightarrow DELY(ON/OFF) 20/20 DELY (ON/FFF) means that the shutter will be turned ON 20cm right from location of Image and OFF 20cm left from the location of image.

Unit is (cm). Able to set between 0 and 99cm.

* The printing should wait until UV Lamp Ready Signal comes out. When Ready signal comes out, then the printing starts. Ready wait_sec will be counted in the Display. Normally, in case of first printing, the printing will begin in 30 sec.

2. VACUUM 🕐

Mode : OFF, ON 2 OFF : RING BLOWER won't work.<LED OFF> ON : RING BLOWER works.<LED ON> % When printing, Ring Brower should be turned on.

4. CAPPING COVER Mode : OFF, ON 2 CLOSE : Capping cover is being closed. OPEN : Capping cover is being opened.

Capping cover is closed. Error message will show up in the CAPPING COVER CLOSE. Headbase won't be down.

Capping cover should be opened, then headbase will be down.



CHECKING LIST RELATED TO POWER

- 1. Cut off MAIN BRAKER.
- 2. Check the power short in the OFF state of all the brakers.
 - The resistance between power source and grounding: O.L is normal.
- 3. Check all the short situation with equipment including AC Line and chassis.
- 4. Separate connector of DC power for main PCB + HEAD PCB.
- 5. Separated power is supplied into each part and its operation is checked. (UV lamp-servo motor-ring blower-controller checked)
- 6. If main power is ON/OFF, able to check whether DC main power is normal or not.
- 7. Connect with connector of DC power source for MAIN PCB+HEAD PCB.
 - Check connecting 24V GND of MAIN, HEAD PCB with chassis GND.
- 8. Main Power is ON --> check the operation status of machine.

ENCORDER CHECKING

- 1. Press CALIB button.
- 2. Press Key of F2> CARRIAGE SELEASE.
- 3. Move the carriage slowly to the right or the left by hand.
- 4. Check the ON/OFF of ENC A, ENC B LED for HEAD PCB.
- Whenever finishing the encoder checking, press down the key of F1> SERVO ON And HOME CHECK
- 6. If the servo is ON again, the carriage moves to the HOME and then the HOME is checked.
- 7. PRIME TEST.
- 8. Check normal status while printing out.
- 9. Keep the cleanness of CODE STRIP. (wipe out with clean close)

*List of Notice

When you clean, never try to use solution, solvent, thinner, acetone, other chemicals, the scale on the code strip can be erased.

Check of Negative Pressure

- 1. Check the movement of COMPRESSOR.
- 2. Check the pressure in the vacuum pressure gauge
 - Setting with pressure value indicated in the sticker for each part.
 - If the negative pressure do not match, the serious problem like nozzle exclusion, ink dropping etc may occur.
- 3. Remove if there is any water left in the inside filter.
 - Beware that water should keep away from power supplying part.
- 4. Remove waste ink if waste ink fill in the Sub Air-Tank.
- 5. Moisture should be drained off from the air tank every other day by opening the drain valve.

* List of Notice

When adjusting the regulator, if there is not any change on pressure, please verify pressure setting value of regulator and hose connecting.

MODEL : : ANAPURNA MV

4. ABNORMAL PRINTING/DECLINE OF PRINTING QUALITY



PRINTING ERROR

- 1. No Printing Image Encoder error
 - → Cleaning of Code Strip (Use clean cloth)
 - \rightarrow Check the gap between Encoder and Code Strip.
 - → Check the status of ON/OFF of LED for Encoder A.B of HEAD PCB
 - \rightarrow Check the angle between encoder and code strip.

POOR PRINTING QUALITY

- 1. Check the negative air pressure: Regulating within the range of graduation in the sticker of each part.
- 2. Check the voltage of head jetting : Check and regulate each head voltage.
- 3. CALIBRATION CHECKING (BI, FEED)
- 4. CARRIAGE SPEED CHECKING: It is possible to have printing deterioration in a speed that is faster than setting speed. (Max speed 10, Quality speed 7)
- 5. Adjust height of HEAD BASE and check the evenness of platen
- 6. If the ink is not curing, it is caused by LV Lamp.
- \rightarrow Check the power of UV Lamp and check the cooling time.
- * List of Notice:

Since the UV Lamp generate a heat, any media that is weak

to the heat can cause the serious damage to the Head by waving of media.

Therefore, when printing out, should set setting interval between each media.

OVERFLOW OF INK

- 1. Verify the ink filter in the refill area. (main reason to overflow)
 - Should remove the air in the air filter.
- 2. Error of level sensor in sub-ink tank.
- 3. Error in negative pressure and connecting tube. (Check the gauge of negative pressure in -0.028 ~ -0.038kgf/ cm²)
- 4. Check whether there is the ink left in the Sub Air Tank or not.
 - \rightarrow Regularly remove the remaining ink after checking.
 - → If the sensor of level begins operating due to the ink filled. lamp of tower and buzzer as well.

MODEL : **:ANAPURNA MV** 5. DRIVER PARAMETER



TEMPERTURE CONTROLLER SETTING

* Please refer the homepage of Autonic for below contents.



PV: Display of value(RED)
 SV: Display fo setting value(Green)
 3 < > <: Control key of setting value</p>

 Chart of control key
 AT Key: Key of autotunning
 MD Key: Mode key
 EV2: EVENT2 Output display lamp
 EV1: EVENT1 Output display lamp
 OUT: Output display lamp
 AT : Autotunning play display lamp
 SV2: SV2 Play display lamp

How to Set and Change the Setting Value (SV)

Name of each part (TZ4ST)

***** The scope of temperature regulation is set for 0~ 45 $^{\circ}$ C originally.



- 1) Switch on the power of heater controller. (Red Switch in the front)
- 2 If setting (resetting) the Temperature setting value, press down << key. The 1 st lamp in SW blinks.





2) Press << key to move to next digit on the left





3) Press UP and Down keys to change the value during blinking.



- 4) Press the MD key when you have finished the temperature setting. It will stop blinking.
 - * This setting method is for TZ4M.
 - The method for TZ4ST, which is installed
 - in our printer, same with different external covering.



Do not change voluntarily because of the controller settings done.

DESCRIPTION OF DRIVER PARAMETER OF SERVO MOTOR -1

NO Symbo		Name and Eurotion	Initial Value	Unit	Customer setting	
NO.	Symbol			Unit	Feed	Carriage
0	*STY	Command system/regenerative brake option selection 0000		0010	0310	
1	*FTY	Feeding function selection	0000		0011	0010
2	*0P1	Function selection 1	0002		0002	0002
3	ATU	Auto tuning	0105		040B	0406
4	*CMX	Electronic gear numerator	1		13107	13107
5	*CDV	Electronic gear denominator	1		8000	8000
6	FED	Movement complete output range	100	μm	100	100
7	PGI	Position loop gain	35	rad/s	150	30
8	*ZTY	Home position return type	0010		0014	0014
9	ZRF	Home position return speed	500	r/min	500	500
10	CRF	Creep speed	10	r/min	10	10
11	ZST	Home position shift distance	0	μm	0	0
12		For manufacturer setting	0		0	0
13	JOG	JOG Jog speed	100	r/min	2000	100
14	*STC	S-pattern acceleration/deceleration time constant	0	ms	0	0
15	*SNO	Station number setting	0	station	1	2
16	*BPS	Communication baudrate selection, alarm history clear	0000		0100	0100
17	MOD	Analog monitor outpu	0100		0100	0100
18	*DMD	Status display selection	0000		0000	0005
19	*BLK	Parameter block	0000		000E	000E

DESCRIPTION OF DRIVER PARAMETER OF SERVO MOTOR-2

20	*OP2	Function selection	0000		0000	0000
21		For manufacturer setting	0002		0002	0002
22	*OP4	Function selection	0000		0000	0000
23	SIC	Serial communications time-out selection	0		0	0
24	FFC	Feed forward gain	0	%	0	0
25	VCO	Override offset	0	mV	0	0
26	TLO	Torque limit offset	0	mV	0	0
27	*ENR	Encoder output pulses	4000	pulse/rev	4000	4000
28	TL1	Internal torque limit	100	%	100	25
29	TL2	Internal torque limi	100	%	100	100
30	*BKC	Backlash compensation	0	pulse	0	0
31	MO1	Analog monitor 1 offset	0	mV	0	0
32	MO2	Analog monitor 2 offset	0	mV	0	0
33	MBR	Electromagnetic brake sequence output	100	ms	100	100
34	GD2	Ratio of load inertia moment to Servo motor inertia moment	70	0.1 times	10	135
35	PG2	Position loop gain	35	rad/s	200	35
36	VG1	Speed loop gain	177	rad/s	600	750
37	VG2	Speed loop gain	817	rad/s	1200	1500
38	VIC	Speed integral compensation	48	ms	4	20
39	VDC	Speed differential compensation	980		980	980
40	JTS	JOG operation acceleration/deceleration time constant	100	ms	0	0
41	ZTS	Home position return operation acceleration/deceleration time constant	100	ms	0	0
42	*ZPS	Home position return position data	0	$\times 10^{\text{STM}\mu\text{m}}$	0	0
43	DCT	Moving distance after proximity dog	1000	$\times 10^{\text{STM}\mu\text{m}}$	1000	1000
44	ZTM	Stopper type home position return stopper time	100	ms	100	100
45	ZTT	Stopper type home position return torque limit value	15	%	15	15

DESCRTION OF DIRVER PARAMETER OF SERVO MOTOR-3

46	*LMP	Software limit +	0	$\times 10^{\text{STM }\mu\text{m}}$	0	0
48				STM		
49	*LMN	Software limit –	0	×10 ^{31101,µ}	0	0
50	≁I DD	Position range output address +	0		0	0
51	^LI I		0	XIU	0	0
52	*I NP	Position range outpot address –	0	∨10 ^{STM µm}	0	0
53			0	~10	0	0
54		For manufacturer setting	0000		0000	0000
55	*OP6	Function selection 6	0000		0000	0000
56		For manufacturer setting	0000		0000	0000
57	*OP8	Function selection 8	0000		0000	0000
58	*OP9	Function selection 9	0000		0000	0000
59	*OPA	Function selection A	0000		0000	0000
60		For manufacturer setting	0000		0000	0000
61	NH1	Machine resonance suppression filter 1	0000		0000	0000
62	NH2	Machine resonance suppression filter 2	0000		0000	0000
63	LPF	Low-pass filter, adaptive vibration suppression control	0000		0000	0000
64	GD2B	Ratio of load inertia moment to Servo motor inertia moment	70	0.1 times	70	70
65	PG2B	Position control gain 2 changing ratio	100	%	100	100
66	VG2B	Speed control gain 2 changing ratio	100	%	100	120
67	VICB	Speed integral compensation changing ratio	100	%	100	100
68	*CDP	Gain changing selection	0000		0000	0000
69	CDS	Gain changing condition	10	(Note)	10	10
						102

DESCRITION OF DRIVER PARAMETER OF SERVO MOTOR-4

70	CDT	Gain changing time constant	1	ms	1	1
71			100		100	100
72		For manufacturer setting	10000		10000	10000
73			10		10	10
74	OUT1	OUT1 output time selection	0	10ms	10	10
75	OUT2	OUT2 output time selection	0	10ms	100	100
76	OUT3	OUT3 output time selection	0	10ms	100	100
77	*SYC1	Selected to program input polarity selection	0000		100	100
78			0001		0000	0000
79			0209		0009	0009
80			060A		080A	080A
81			1918		0706	0706
82			030B		020B	020B
83			0504		0504	0504
84		For manufacturer setting	0102		0002	0002
85			0000		0000	0000
86			0005		0005	0005
87			120E		0D04	0D04
88			0102		0102	0102
89			0		0	0
90			0		0	0

No.	Start-up sequence	Fault	Investigation	Possible cause	Reference
1	Power on	 LED is not lit. LED flickers. 	Not improved if connectors CN1A, CN1B, CN2 and CN3 are disconnected.	 Power supply voltage fault Servo amplifier is faulty. 	\square
			Improved when connectors CN1A and CN1B are disconnected.	Power supply of CNP1 cabling is shorted.	
			Improved when connector CN2 is disconnected.	 Power supply of encoder cabling is shorted. Encoder is faulty. 	
			Improved when connector CN3 is disconnected.	Power supply of CN3 cabling is shorted.	
		Alarm occurs.	Refer to Section 11.2 and rem	love cause.	Section 11.2
2	Switch on servo-on	Alarm occurs.	Refer to Section 11.2 and rem	iove cause.	Section 11.2
	signal.	Servo motor shaft is not servo-locked	 Check the display to see if the servo amplifier is 	1. Servo-on signal is not input. (Wiring mistake)	Section 7.3.2
		(is free).	ready to operate. 2. Check the external I/O signal indication to see if the servo-on (SON) signal is ON.	 24VDC power is not supplied to COM. 	
3	Gain adjustment	Rotation ripples (speed fluctuations) are large at low speed.	 Make gain adjustment in the following procedure: 1. Increase the auto tuning response level. 2. Repeat acceleration and deceleration several times to complete auto tuning. 	Gain adjustment fault	Chapter 7
		Large load inertia moment causes the servo motor shaft to oscillate side to side.	If the servo motor may be run with safety, repeat acceleration and deceleration several times to complete auto tuning.	Gain adjustment fault	Chapter 7

İ	4	Cyclic operation	Position shift occurs	Confirm the cumulative	Pulse counting error, etc.	
I				command pulses, cumulative	due to noise.	
I				feedback pulses and actual		
l				servo motor position.		

	Display	(Note 2) Alarm code				Alarm deactivation		
		CN1B-19 pin	CN1A-18 pin	CN1A-19 pin	Name	Power OFF→ON	Press "SET" on current alarm screen.	Alarm reset (RES) signal
	AL.10	0	1	0	Undervoltage	0	0	0
	AL.12	0	0	0	Memory error 1	0		
	AL.13	0	0	0	Clock error	0		
	AL.15	0	0	0	Memory error 2	0		
	AL.16	1	1	0	Encoder error 1	0		
	AL.17	0	0	0	Board error	0		
	AL.19	0	0	0	Memory error 3	0		
	AL.1A	1	1	0	Motor combination error	0		
	AL.20	1	1	0	Encoder error 2	0		
	AL.24	1	0	0	Main circuit error	0		
Marms	AL.25	1	1	0	Absolute position erase	0		
	AL.30	0	0	1	Regenerative error	O (Note 1)	O (Note 1)	O (Note 1)
	AL.31	1	0	1	Overspeed	0	0	0
	AL.32	1	0	0	Overcurrent	0	0	0
	AL.33	0	0	1	Overvoltage	0		
	AL.35	1	0	1	Command pulse frequency error	0	0	0
	AL.37	0	0	0	Parameter error	0		
	AL.39	0	0	0	Program error	0		
	AL.45	0	1	1	Main circuit device overheat	0	0	Q
	AL.46	0	1	1	Servo motor overheat	0	0	0
	AL.50	0	1	1	Overload 1	O (Note 1)	O (Note 1)	O (Note 1)
	AL.51	0	1	1	Overload 2	O (Note 1)	O (Note 1)	O (Note 1)
	AL.52	1	0	1	Error excessive	0	0	0
	AL.63	1	0	1	Home position return incomplete	0	0	0
	AL.64	1	0	1	Home position setting error	0	0	0
	AL.8A	0	0	0	Serial communication time-out error	0	0	0
	AL.8E	0	0	0	Serial communication error	0	0	0
	88888	0	0	0	Watchdog	0		



Note: 1. Deactivate the alarm about 30 minutes of cooling time after removing the cause of occurrence.

2. 0: Pin-SG off (open)

1: Pin-SG on (short)

Display	Name	Definition	Cause	Action
AL.10	Undervoltage	Power supply voltage dropped. MR-J2S-□CL: 160VAC or less MR-J2S-□CL1: 83VAC or less	 Power supply voltage is low. There was an instantaneous control power failure of 60ms or longer. Shortage of power supply capacity caused the power supply voltage to drop at start, etc. Power was restored after the bus voltage had dropped to 200VDC. (Main circuit power switched on within 5s after it had switched off.) 	Review the power supply.
			5. Faulty parts in the servo amplifier Checking method Alarm (AL.10) occurs if power is switched on after disconnection of all cables but the control circuit power supply cables.	Change the servo amplifier.
AL.12	Memory error 1	RAM, memory fault	Faulty parts in the servo amplifier	Change the servo amplifier.
AL.13	Clock error	Printed board fault	Checking method Alarm (any of AL.11 and 13) occurs if power is switched on after disconnection of all cables but the control circuit power supply cables.	
AL.15	Memory error 2	EEP-ROM fault	Faulty parts in the servo amplifier Checking method Alarm (AL.15) occurs if power is switched on after disconnection of all cables but the control circuit power supply cables. The number of write times to EEP- ROM exceeded 100,000.	Change the servo amplifier.
AL.16	Encoder error 1	Communication error occurred	 Encode connector (CN2) disconnected. 	Connect correctly.
-------	-----------------------	---	---	-----------------------------
		between encoder	2. Encoder fault	Change the servo motor.
		and servo amplifier.	 Encoder cable faulty (wire breakage or short) 	Repair or change the cable.
AL.17	Board error	CPU/parts fault	Faulty parts in the servo amplifier	Change the servo amplifier.
AL.19	Memory error 3	ROM memory fault	Checking method Alarm (A.17 or A.18) occurs if power is switched on after disconnection of all cables but the control circuit power supply cables.	
AL 1A	Motor	Wrong combination	Wrong combination of servo amplifier	Use correct combination.
	combination error	of servo amplifier and servo motor.	and servo motor connected.	
AL.20	Encoder error 2	Communication error occurred	 Encoder connector (CN2) disconnected. 	Connect correctly.
		between encoder and	Encoder fault	Cange the servo motor.
		servo amplifier.	 Encoder cable faulty (wire breakage or shorted) 	Repair or change the cable.
AL.24	Main circuit error	Ground fault occurred at the servo motor outputs (U,V	 Power input wires and servo motor output wires are in contact at main circuit terminal block (TE1). 	Connect correctly.
		and W phases) of the servo amplififer.	 Sheathes of servo motor power cables deteriorated, resulting in ground fault. 	Change the cable.
			 Main circuit of servo amplifier failed. 	Change the servo amplifier.
			Checking method AL.24 occurs if the servo is switched on after disconnecting the U, V, W power cables from the servo amplifier.	

AL 25	Absolute	Absolute position	 Reduced voltage of super capacitor 	After leaving the alarm occurring for a few
	position erase	data in error	in encoder	minutes, switch power off, then on again. Always make home position setting again
			2 Battery voltage low	Change hatters
			3. Battery cable or battery is faulty	Always make home position setting again
		Power was switched	4 Super capacitor of the absolute	After leaving the alarm occurring for a few
		on for the first time	position encoder is not charged	minutes switch power off then on again
		in the absolute	Feering and an under an and an and a	Always make home position setting again
		position detection		· · · · · · · · · · · · · · · · · · ·
		system.		
AL.30	Regenerative	Permissible	 Wrong setting of parameter No. 0 	Set correctly.
	alarm	regenerative power	Built in regenerative brake resistor	Connect correctly
		of the built in	or regenerative brake option is not	
		regenerative brake	connected.	
		resistor or	3. High duty operation or continuous	 Reduce the frequency of positioning.
		option is exceeded	regenerative operation caused the	2. Use the regenerative brake option of
		option is encounted.	the regenerative brake option to be	3 Reduce the load
			exceeded.	5. Reduce the load.
			Checking method	
			Call the status display and check	
			the regenerative load ratio	
			the regenerative load ratio.	
			Power supply voltage is abnormal.	Review power supply
			MR-J2S-□CL:260VAC or more	
			MR-J2S-CL1-135VAC or more	
			5. Built in regenerative brake resistor	Change servo amplifier or regenerative
			or regenerative brake option	brake option.
		Regenerative	a D	Change the como annifiar
		transistor fault	6. Regenerative transistor faulty.	change the serve amplifier.
			Checking method	
			1) The regenerative brake option	
			has overheated abnormally.	
			2) The alarm occurs even after	
			removal of the built-in	
			regenerative brake resistor or	
			regenerative brake option	
			regenerative state option.	

Displa	ay Name	Definition	Cause	Action
AL.31	Overspeed	Speed has exceeded the instantaneous permissible speed	 Input command pulse frequency exceeded the permissible instantaneous speed frequency 	Set command pulses correctly.
		,	 Small acceleration/deceleration time constant caused overshoot to be large. 	Increase acceleration/deceleration time constant.
			 Servo system is instable to cause overshoot. 	 Re-set servo gain to proper value. If servo gain cannot be set to proper value: Reduce load inertia moment ratio; or Reexamine acceleration/ deceleration time constant
			 Electronic gear ratio is large (parameters No. 4, 5) 	Set correctly.
			5. Encoder faulty.	Change the servo motor.
AL.32	Overcurrent	Current that flew is higher than the	 Short occurred in servo amplifier output phases U, V and W. 	Correct the wiring.
		permissible current of the servo amplifier.	2. Transistor (IPM) of the servo amplifier faulty. Checking method Alarm (AL.32) occurs if power is switched on after U,V and W are disconnected.	Change the servo amplifier.
			 Ground fault occurred in servo amplifier output phases U, V and W. 	Correct the wiring.
			 External noise caused the overcurrent detection circuit to misoperate. 	Take noise suppression measures.

AL.33	Overvoltage	Converter bus voltage exceeded	1. Lead of built in regenerative brake resistor or regenerative brake	 Change lead. Connect correctly.
		400VDC.	option is open or disconnected.	
			2. Regenerative transistor faulty.	Change servo amplifier
			Wire breakage of built-in	1. For wire breakage of built-in
			regenerative brake resistor or	regenerative brake resistor, change
			regenerative brake option	servo amplifier.
				2. For wire breakage of regenerative brake
				option, change regenerative brake
				option.
			4. Capacity of built-in regenerative	Add regenerative brake option or increase
			brake resistor or regenerative	capacity.
			brake option is insufficient.	
			5. Power supply voltage high.	Review the power supply.
AL.35	Command pulse	Input pulse	1. Pulse frequency of the manual	Change the pulse frequency to a proper
	frequency error	frequency of the	pulse generator is too high.	value.
		command pulse is	2. Noise entered the pulses of the	Take action against noise.
		too high.	manual pulse generator.	
			3. Manual pulse generator failure	Change the manual pulse generator.

AL.37	Parameter	Parameter setting is	 Servo amplifier fault caused the narameter setting to be rewritten 	Change the servo amplifier.
		NIGHE.	 Regenerative brake option not used with servo amplifier was selected in parameter No.0. 	Set parameter No.0 correctly.
			 Value outside setting range has been set in some parameter. 	Set the parameter correctly.
			 Value outside setting range has been set in electronic gear. 	Set parameters No. 4, 5 correctly.
			 Opposite sign has been set in software limit increasing side (parameters No. 46, 47). Similarly, opposite sign has been set in software limit decreasing side (parameters No. 48, 49). 	Set parameters No. 46 to 49 correctly.
			 Opposite sign has been set in position range output address increasing side (parameters No. 50, 51). Similarly, opposite sign has been set in position range output address decreasing side (parameters No. 52, 53). 	Set parameters No. 50 to 53 correctly.
			 The number of write times to EEP- ROM exceeded 100,000 due to parameter write, program write, etc. 	Change the servo amplifier.
AL.39	Program error	Program data is abnormal	 Servo amplifier fault caused the program data to be rewritten. 	Change the servo amplifier.
			Command argument is out of the setting range.	Programming correctly.
			 The number of write times to EEP- ROM exceeded 100,000 due to parameter write, program write, etc. 	Change the servo amplifier.

AL.45	Main circuit	Main circuit device	 Servo amplifier faulty. 	Change the servo amplifier.
	device overheat	overheat	The power supply was turned on	The drive method is reviewed.
			and off continuously by overloaded	
			status.	
			Air cooling fan of servo amplifier	 Exchange the cooling fan or the servo
			stops.	amplifier.
				Reduce ambient temperature.
AL.46	Servo motor	Servo motor	1. Ambient temperature of servo motor	Review environment so that ambient
	overheat	temperature rise	is over 40°C.	temperature is 0 to 40°C.
		actuated the	Servo motor is overloaded.	1. Reduce load.
		thermal protector.		Review operation pattern.
				Use servo motor that provides larger
				output.
			Thermal protector in encoder is	Change servo motor.
			faulty.	

AL.50	Overload 1	Load exceeded overload protection characteristic of servo amplifier.	 Servo amplifier is used in excess of its continuous output current. 	 Reduce load. Review operation pattern. Use servo motor that provides larger output.
			 Servo system is instable and hunting. 	 Repeat acceleration/ deceleration to execute auto tuning. Change auto tuning response setting. Set auto tuning to OFF and make gain adjustment manually.
			Machine struck something.	 Review operation pattern. Install limit switches.
			 Wrong connection of servo motor. Servo amplifier's output terminals U, V, W do not match servo motor's input terminals U, V, W. 	Connect correctly.
			5. Encoder faulty. Checking method When the servo motor shaft is rotated with the servo off, the cumulative feedback pulses do not vary in proportion to the rotary angle of the shaft but the indication skips or returns midway.	Change the servo motor.

AL.51	Overload 2	Machine collision or the like caused max.	1. Machine struck something.	 Review operation pattern. Install limit switches.
		output current to flow successively for several seconds. Servo motor locked:	 Wrong connection of servo motor. Servo amplifier's output terminals U, V, W do not match servo motor's input terminals U, V, W. 	Connect correctly.
		1s or more During rotation: 2.5s or more	 Servo system is instable and hunting. 	 Repeat acceleration/deceleration to execute auto tuning. Change auto tuning response setting. Set auto tuning to OFF and make gain adjustment manually.
			4. Encoder faulty. Checking method When the servo motor shaft is rotated with the servo off, the cumulative feedback pulses do not vary in proportion to the	Change the servo motor.
			rotary angle of the shaft but the indication skips or returns midway.	
AL.52	Error excessive	The droop pulse value of the	 Acceleration/deceleration time constant is too small. 	Increase the acceleration/deceleration time constant.
		deviation counter exceeded 2.5	 Internal torque limit 1 (parameter No.28) is too small. 	Increase the torque limit value.
		rotations.	 Motor cannot be started due to torque shortage caused by power supply voltage drop. 	 Review the power supply capacity. Use servo motor which provides larger output.
			 Position control gain 1 (parameter No.7) value is small. 	Increase set value and adjust to ensure proper operation.
			 Servo motor shaft was rotated by external force. 	 When torque is limited, increase the limit value. Reduce load. Use servo motor that provides larger output.
			6. Machine struck something.	1. Review operation pattern. 2. Install limit switches.
			7. Encoder faulty	Change the servo motor.
			 Wrong connection of servo motor. Servo amplifier's output terminals U, V, W do not match servo motor's input terminals U, V, W 	Connect correctly.

AL.63	Home position return incomplete	In incremental system: 1. Positioning operation was performed without home position return. 2. Home position return ended abnormally.	 Positioning operation was performed without home position return. Home position return speed could not be decreased to creep speed. Limit switch was actuated during home position return starting at other than position beyond dog. 	 Perform home position return. Review home position return speed/creep speed/moving distance after proximity dog.
		In absolute position detection system: 1. Positioning operation was performed without home position setting. 2. Home position setting ended abnormally.	 Positioning operation was performed without home position setting. Home position setting speed could not be decreased to creep speed. Limit switch was actuated during home position setting starting at other than position beyond dog. 	 Perform home position setting. Review home position setting speed/creep speed/moving distance after proximity dog.
AL.64	Home position setting error	Home position setting could not be made.	 Droop pulses remaining are greater than the in-position range setting. 	Remove the cause of droop pulse occurrence
			 Command pulse entered after clearing of droop pulses. 	Do not enter command pulse after clearing of droop pulses.
			3. Creep speed high.	Reduce creep speed.
AL.8A	Serial	RS-232C or RS-422	1. Communication cable breakage.	Repair or change communication cable
	communication time-out error	communication stopped for longer	 Communication cycle longer than parameter No. 23 setting. 	Set correct value in parameter.
		than the time set in parameter No.23.	3. Wrong protocol.	Correct protocol.

AL.8E	Serial communication	Serial communication error	 Communication cable fault (Open cable or short circuit) 	Repair or change the cable.
	error	servo amplifier and communication device (e.g. personal computer).	 Communication device (e.g. personal computer) faulty 	Change the communication device (e.g. personal computer).
88888	Watchdog	CPU, parts faulty	Fault of parts in servo amplifier	Change servo amplifier.
			Checking method Alarm (88888) occurs if power is switched on after disconnection of all cables but the control circuit power supply cables.	

Display	Name	Definition	Cause	Action
AL.92	Open battery	Absolute position	1. Battery cable is open.	Repair cable or changed.
	cable warning	detection system battery voltage is low.	Battery voltage dropped to 2.8V or less.	Change battery.
AL.97	Program operation disable	Program was started in a program operation disable status.	After a program change, the program was started without the servo amplifier being powered off/on.	Power off/on the servo amplifier.
AL.98	Software limit warning	Software limit set in parameter is reached.	 Software limit was set within actual operation range. 	Set parameter No. 48 to 51 correctly.
			 Program of position data in excess of software limit was executed. 	Set program correctly.
			 Software limit was reached during JOG operation or manual pulse generator operation. 	Perform operation within software limit range.
AL.9F	Battery warning	Voltage of battery for absolute position detection system reduced.	Battery voltage fell to 3.2V or less.	Change the battery.
AL.E0	Excessive regenerative warning	There is a possibility that regenerative power may exceed permissible regenerative power of built-in regenerative brake resistor or regenerative brake option.	Regenerative power increased to 85% or more of permissible regenerative power of built-in regenerative brake resistor or regenerative brake option. Checking method Call the status display and check regenerative load ratio.	 Reduce frequency of positioning. Change regenerative brake option for the one with larger capacity. Reduce load.

AL.E1	Overload warning	There is a possibility that overload alarm 1 or 2	Load increased to 85% or more of overload alarm 1 or 2 occurrence level.	Refer to AL.50, AL.51.
		may occur.	Cause, checking method Refer to AL.50,51.	
AL.E3	Absolute position	Absolute position encoder	1. Noise entered the encoder.	Take noise suppression
	counter warning	pulses faulty.		measures.
			Encoder faulty.	Change servo motor.
AL.E6	Servo forced stop	EMG-SG are open.	External forced stop was made valid.	Ensure safety and deactivate
	warning		(EMG-SG opened.)	forced stop.
AL.E9	Main circuit off	Servo was switched on		Switch on main circuit power.
	warning	with main circuit power		
		off.		

MODEL : : ANAPURNA MV

6.ELECTRIC DIAGRAM/PCB



TOTAL ELECTRONIIC SYSTEM CIRCUIT DIAGRAM



* Bigger original circuit diagram is attached for understanding.

POWER BOX ELECTRIC SYSTEM WIRING DIAGRAM



* Bigger original circuit diagram is attached for understanding.





SWITCHBOARD – DESCRIPTION OF EACH PART

- Input terminal block for main power
- 2 Initial short circuit breaker, MCCB, Main short circuit breaker
- 3 Noise filter

1

- 4 If Main MC-START button is pressed, begin to work.
- 5 2nd short circuit breaker(MCCB) UV Lamp, Motor driver power, Ring blower, Controller rack.
- $\binom{6}{6}$ MC for Ring Blow Operation Ring Blower Select Switch is turned on, begin to operate.
- (7) SMPS supply the power to both main MC of circuit board and FAN.

LAMP POWER SYSTEM CIRCUIT DIAGRAM



* Bigger original circuit diagram is attached for understanding.

UV LAMP AND LMAP CASE



85, 120w/cm



UV LAMP – PART DESCRIPTION

2

3

4

5

6

7



- Lamp power connector (4P)
- Lamp Signal Connector (7P)
- Lamp shutter signal connector(2P)
- Lamp shutter closing air compressor tube.
- Lamp shutter opening air compressor tube
- Lamp House Exhaust DC FAN
- Lamp case induction AC FAN

NAME OF EACH PART FOR LAMP POWER



INNER STRUCTURE OF LAMP POWER



HOW TO SET POWER LAMP



Power Input Voltage Tap Setting (ex: 220V, 60Hz.)



DESCRIPTION OF TAB

Power	204V	230V
Frequency	50Hz	60Hz

DIAGRAM – TROUBLE CHECK CHART



* Bigger original circuit diagram is attached for understanding.

132

INK SUPPLY FLOW DIAGRAM



DIAGRAM – MAIN INK SUPPLY PART



1. Main Refill Motor



2. Refill motor



3. Ink Filter



4. Ink Hose Fixing part, up, down



5. Sub Ink Tank



6. Solution Mini Valve



7. Head

DIAGRAM – Pneumatic flow chart&circuit



DIAGRAM – KEY PART OF AIR COMPRESSION (1)







DIAGRAM – KEY PARTS OF AIR COMPRESSION (2)



DIAGRAM – KEY PARTS OF AIR COMPRESSION (3)





1. Purge Switch







2. Regulator of Air Compression (0.03MPa)

TOTAL SYSTEM DIAGRAM



* Bigger original circuit diagram is attached for understanding.

TOTAL PCB LAYOUT



* Bigger original circuit diagram is attached for understanding.

PCB LIST

PCB LIST

1. MAIN PCB	(UVM-03)	P.143
2. NETSUB PCB	(UVN-03)	P.152
3. HEAD PCB	(UVH-03)	P.160
4. REFILL PCB	(UVR-03)	P.169
5. CARTRIDGE PCB #1 ~ #4	(UVC-03)	P.177
6.HEAD LIFT PCB	(UVL-01)	P.192
7. SUB PCB	(UVS-03)	P.198
8. I/F PCB	(UVI-01)	P.207
9. CONTROL PCB	(UVCT-01)	P.211

PCB – Main + NET SUB PCB



Part #; UVM-03

MAIN FUNCTION

1. It process print data received from sub-net PCB and transfer it to HEAD PCB.

2. All kinds of device is controlled by communicating Thru SUB PCB#2 and Core Cable.

3. Receive operation power supplied thru HEAD PCB.

PCB - Main PCB



Part #; UVM-03

MAIN FUNCTION

1. It process print data received from sub-net PCB and transfer it to HEAD PCB.

2. All kinds of device is controlled by communicating Thru SUB PCB#2 and 15P Core Cable

3. Receive operation power supplied thru HEAD PCB.

PCB - Main PCB



Part #; UVM-03

CONNECTOR CONNECTION MAP

- 1. J1 Disconnection
 - J2 2X45 (1.27 Arrangement) --> Net Sub JP1
 - J3 2X50 (1.27 Arrangement) --> Net Sub JP2
 - J4 Disconnection J5 Disconnection
 - JP1 Disconnection
 - JP2 HRS-PCN10-64P-254DSA --> Head J15
 - JP3 D-SUB 15(FEMALE) --> Sub #2 J23
PCB – MAIN PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

HEAD F	РСВ						
J1	HOME	1	VDD5V		HOME SENSOR PCB	1	VDD5V(RED)
	5045-3P	2	SEN-HOME		5051-3P	2	SEN-HOME-OUT(YELLOW)
		3	GND			3	GND(BLACK)
.12	ĸ	1	SIGNAL (BLACK)		FLOAT SENSOR K	1	SIGNAL K(BLACK)
	5268-2P	2	GND (BLACK)		5264-2P	2	GND(BLACK)
	5200 EI	~ ~			5204 21	~ ~	
.13	ENCODER	1	B ANGLE		ENCODER	1	ENC-B(YELLOW)
00	GI-I GC4P	2			9740(180dpi)	2	5V(RED)
	ANGLE	3			L GCONNECTOR	3	ENC-A(BLUE)
	ANGLE	4	GND		EGOOMMEDICIT	1	GND(BLACK)
			GIND				
И	<u> </u>	1	SIGNAL C (BLACK)		FLOAT SENSOR C	1	SIGNAL C(BLACK)
	5268-2P	2			5264-2P	2	CND(PLACK)
	5200 ZF	2	GIND (DLAGIV		5204 21	۷	GIND(BLACK)
15	M	1	SIGNAL M (BLACK)			1	SIGNAL M(BLACK)
10	M 5269_2D				FLOAT SENSOR, M	0	
	5206-2F	2	GIND (BLAGN)		5204-2F	2	GIND(BLACK)
10					FLOAT SENSOR Y	- 1	
10	1 5069 0D		OND (DLACK)		FLUAI SENSUR, T	1	
	5206-2F	2	GIND (BLAGN)		5204-2F	2	GIND(BLACK)
17	0175			()		- 1	
J/	5069 40		OND (DLACK)		SIZE SENSUR	1	
	5200-4P	2	GIND (BLACK)	()()()	5264-4P	2	
		3	SEN-SIZE-I (TELLU	(VV)		3	
		4	VDD5V (RED)			4	SV+(RED)
10	10	1				1	
10	5069 0D	0	SIGNAL LU (BLAUN)		FLUAI SENSUR, LU	1	
	5200-2P	2	GIND (BLACK)		5264-2P	2	GIND(BLACK)
10	1.14					- 1	
19	E069.0D		OND (DLACK)		FLUAI SENSUR, LM	1	
	5206-2F	2	GIND (BLAGN)		5204-2F	2	GIND(BLACK)
11.0	TEMD SENI	1	CEN1				
310	TEMP_SENT			NOT USED			
		2	GND	NOT USED			
14.4	SDADE	1	SIGNAL SDADE				
011	5769_2D			NOT USED			
	5208-2F	2	GND	NOT USED			
11.0	SOLUTION	1	SIGNAL S (DLACK)			1	
312	50E0110N	0	CND (DLACK)	COLUTION CUR INK TANK		0	CND(RLACK)
	5200-2F	2	GIND (DLAGIV	SOLUTION SUB INK TANK	30201101	۷	GIND(BLACK)
11.2	TEMD SENO	1	CEND				
010	EDER-DD			NOT USED			
	5206-2F	2	GND	NOT USED			
11.4		1	DC 241/				
014				NOT USED			
	D2F-VI	2	CONTROL GIND	INOT USED			
11.5		1	DC12V			1	DC12V
010		1	DC12V		1:1 CONNECT	1	DC12V
	-64S-254DSA K	2	DC12V		HRS-PCN10-	2	
	040-20400A K	<u>د</u>	DC12V		64P-254DSA K	ر ۸	DC12V
		4	DUIZV	1	041 20400A N	4	DUIZV

5	L h DATA1		5	L h DATA1
6	R h DATA1		6	R h DATA1
7	L h DATA2		7	L h DATA2
8	R h DATA2		8	R h DATA2
 9	L h DATA3		9	L h DATA3
10	B h DATA3	 	10	B h DATA3
 11	L h DATA4	 	11	L b DATA4
 12	B h DATA/	 	12	B b DATA4
 13		 	13	
 14			14	
 14			14	
 15			10	
 17			17	
 10			10	
 10	CTD2 I		10	
 19			19	STDOL I
 20	OND	 	20	
 21	GND	 	21	
 22	GND	 	22	
 23		 	23	
 24	ULK I	 	24	
 25	UPIL I	 	25	
 26	LOAD I	 	26	LOAD I
 27	DP2H I	 	27	DP2H I
 28	LAI I		28	LAI I
 29	DP2L I	 	29	
 30	DADAT I		30	DADAT I
 31	D GNT I	 	31	D CIVIT I
 32	DACLK I	 	32	DACLK I
 33	AD SEL	 	33	AD SEL
 34	DALD I		34	DALD I
 35	SEN_HUME	 	35	SEN_HOME
 36	SEN_SIZE		36	SEN_SIZE
 37	ENC_A		37	ENC_A
 38	ENS_B		38	ENS_B
 39	GND		39	GND
 40	GND		40	GND
 41	ANO		41	ANO
 42	AN4		42	AN4
 43	AN1		43	AN1
 44	AN5	 	44	AN5
 45	AN2	 	45	AN2
 46	AN6	 	46	ANG
 47	AN3	 	47	AN3
 48	AN7	 	48	AN7
 49	GND	 	49	GND
 50	GND		50	GND
 51	INKL 1		51	INKL 1
 52	INKL 2		52	INKL 2
 53	INKL 3		53	INKL 3
 54	INKL 4		54	INKL 4
 55	INKL 5		55	INKL 5
56	INKL 6		56	INKL 6

		57	INKL 7		57	INKL 7	
		58	INKL 8		58	INKL 8	
		59	GND		59	GND	
		60	GND		60	GND	
		61	N.C		61	N.C	
		62	N.C		62	N.C	
		63	N.C		63	N.C	
		64	N.C.		64	N.C	
J16	INK K	1	VH-POW	CARTRIDGE PCB. J7	1	GND	
	5597-30P	2	VH-POW	5597-30P	2	GND	
	straight Type	3	VH-POW		3	STBCI	
		4	GND		4	LOAD	
		5	DC12V		5	STB3	
		6	GND		6	STB2	
		7	DP1H		7	STB1	
		8	DP1I		8	LAT	
		9	DP2H		9	CLK	
		10	DP2I		10	R-DAT1	
		11	DA1 (K)		11	I -DAT1	
		12	DA2(K)		12	B-DATO	
		13	AD1 (K)		13	I -DATO	
		14	GND		14	GND	
		15	VDD5V		15	VDD5V	
		16	VDD5V		16	VDD5V	
		17	GND		17	GND	
		18	L-DATO(K)		18	AD1	
		19	R-DATO(K)		19	DA2	
		20	I -DAT1(K)		20	DA1	
		21	I -DAT1 (K)		21	DP2I	
		22	CLK		22	DP2H	
		23	I AT		23	DP1I	
		24	STB1		24	DP1H	
		25	STB2		25	GND	
		26	STB3		26	DC12V	
		27	LOAD		27	GND	
		28	STBCL		28	VH-POW	
		29	GND		29	VH-POW	
		30	GND		30	VH-POW	
J17	INK_C	1	VH-POW	CARTRIDGE PCB, J7	1	GND	
-	5597-30P	2	VH-POW	5597-30P	2	GND	
	straight Type	3	VH-POW		3	STBCL	
		4	GND		4	LOAD	
		5	DC12V		5	STB3	
		6	GND		6	STB2	
		7	DP1H		7	STB1	
		8	DP1L		8	LAT	
		9	DP2H		9	CLK	
		10	DP2L		10	R-DAT1	
		11	DA1 (C)		11	L-DAT1	
		12	DA2(C)		12	R-DAT0	

		13	AD1(C)		13	L-DAT0	
		14	GND		14	GND	
		15	VDD5V		15	VDD5V	
		16	VDD5V		16	VDD5V	
		17	GND		17	GND	
		18	I = DATO(C)		18		
		19	B = DATO(C)		19	DA2	
		20	I = DAT1(C)		20		
		21	L = DAT1(C)	 	21		
		22			22	DP2H	
		22	LAT		22		
		23	CTD1		23		
		24	стро		24	CND	
		25	CTD2		25		
		20	1040		20	CND	
		27	CTROL		27		
		20	CND		20		
		29		 	29		
			GND	 		VITEOW	
11 0		1			1		
110		1	VIT-FOW	 EFOT 20D	1		
	SS97-SUP	2	VH-POW	 5597-30P	2		
	straight Type	3		 	3		
		4			4	CTD2	
		5		 	5	OTDO	
		7		 	0	OTD1	
		/		 	/		
		0	DPIL	 	0		
		10			10		
		10		 	10		
		10			10		
		12		 	12		
		1.1		 	13		
		14		 	14		
		10	VDDGV	 	10		
		17			17		
		10			10		
		10			10		
		19			19		
		20			20		
		21			21		
		22			22		
		24	CTD1		23		
		24	CTDO		24	GND	
		25	CTD2		25		
		20			20	CND	
		27	STRO	 	27		
		20	GND		20		
		29	GND		29		
			GIND		30	VITEOW	
11 0		1	VH-POW		1	GND	
013	5597-30P	2	VH-POW	5597-30P	0	GND	
	3307 001	Z		0001 001	<	UND .	

	straight Type	3 \	/H-POW		3	STBCL
		4 0	SND		4	LOAD
		5 [DC12V		5	STB3
		6 0	SND		6	STB2
		7 [)P1H		7	STB1
		8 6			8	LAT
		9 6			9	
		10 0	2020		10	D DAT1
		11 0			11	L DATI
		10 5			10	
		12 L			12	
		13 F		 	13	L-DAIU
		14 0	JND DDDV	 	14	GND
		15 V	DD5V		15	VDD5V
		16 V	/DD5V	 	16	VDD5V
		17 (and	 	17	GND
		18 L	-DAI0(Y)	 	18	AD1
		19 F	R-DATO(Y)		19	DA2
		20 L	-DAT1(Y)	 	20	DA1
		21 L	-DAT1(Y)		21	DP2L
		22 0	CLK	 	22	DP2H
		23 L	.AT		23	DP1L
		24 5	STB1		24	DP1H
		25 8	STB2		25	GND
		26 5	STB3		26	DC12V
		27 L	.OAD		27	GND
		28 5	STBCL		28	VH-POW
		29 0	AND		29	VH-POW
		30 0	and		30	VH-POW
.120	POWER CON	1 F)C24V	SUB#2 PCB	1	DC24V
	6P	2 [0C24V	POWER CON 6P	2	DC24V
		3 \	/HPOW		3	VHPOW(FIRE-HV)
		4 \			4	VHPOW(FIRE-HV)
		5 0	AND.		5	GND
		6 0			6	GND
		00			0	GIVE
121	INKIC	1 \			1	CND
021	5597-30P	2 \		5597-30P	2	GND
	etraight Type	2 1		0007 001	2	STROL
	Straight 1900	4 0				
		4 0			4	CTD2
		5 L			5	0100
		7 5			7	
		/ L			/	
		0 L		 	8	
		91		 	9	
		10 L			10	R-DAT
		11 L	JAT(LC)		11	L-DALI
		12 [JA2(LC)	 	12	R-DAIO
		13 A	AUT (LC)	 	13	L-DAI0
		14 0	<u>and</u>	 	14	GND
		15 \	/DD5V	 	15	VDD5V
		16 \	/DD5V		16	VDD5V

		17 GND		17	GND
		18 L-DAT0(LC)		18	AD1
		19 R-DAT0(LC)		19	DA2
		20 L-DAT1(LC)		20	DA1
		21 L-DAT1(LC)		21	DP2L
		22 CLK		22	DP2H
		23 LAT		23	DP1L
		24 STB1		24	DP1H
		25 STB2		25	GND
		26 STB3		26	DC12V
		27 LOAD		27	GND
		28 STBCL		28	VH-POW
		29 GND		29	VH-POW
		30 GND		30	VH-POW
J22	INK_LM	1 VH-POW	CARTRIDGE PCB, J7	1	GND
	5597-30P	2 VH-POW	5597-30P	2	GND
	straight Type	3 VH-POW		3	STBCL
		4 GND		4	LOAD
		5 DC12V		5	STB3
		6 GND		6	STB2
		7 DP1H		7	STB1
		8 DP1L		8	LAT
		9 DP2H		9	CLK
		10 DP2L		10	R-DAT1
		11 DA1(LM)		11	L-DAT1
		12 DA2(LM)		12	R-DAT0
		13 AD1(LM)		13	L-DAT0
		14 GND		14	GND
		15 VDD5V		15	VDD5V
		16 VDD5V		16	VDD5V
		17 GND		17	GND
		18 L-DAT0(LM)		18	AD1
		19 R-DAT0(LM)		19	DA2
		20 L-DAT1(LM)		20	DA1
		21 L-DAT1(LM)		21	DP2L
		22 CLK		22	DP2H
		23 LAT		23	D01L
		24 STB1		24	DP1H
		25 STB2		25	GND
		26 STB3		26	DC12V
		27 LOAD		27	GND
		28 STBCL		28	VH-POW
		29 GND		29	VH-POW
		30 GND		30	VH-POW

PCB - NET SUB PCB



MAIN FUNCTION

 Connected with Main PCB. Either transfer output data received thru LAN port or be used when updating files.

Part #; UVN-03

PCB - NET SUB PCB



Part #; UVN-03

CONNECTOR CONNECTION MAP

U3 UTP CABLE ---> LAN CABLE JP1 2X45 (1.27 Arrangement) --> Main J2 JP2 2X50 (1.27 Arrangement) --> Main J3

PCB – NET SUB PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

NET_SUB								
U3		1	TD+ TPTX+	GORE CABLE	RJ45	1	-	
		2	TD- TPTX-	LAN	UTP CABLE	2	-	
		3	TCT		(LAN)	3	-	
		4	NC1			4	N.C	
		5	NC2			5	N.C	
		6	RCT			6	-	
		7	RD+ TPRX+			7	N.C	
		8	RD- TPRX-			8	N.C	
		9	GRN+					
		10	GRN-					
		11	YEL-					
		12	YEL+					
		13	SHIELD1					
		14	SHIELD2					
JP1	HEADER 2×45	1	VDD5V		MAIN, J2	1	VDD5V	
		2	VDD5V		HEADER 2×45	2	VDD5V	
		3	D0			3	AO	
		4	AO			4	DATAO	
		5	D1			5	A1	
		6	A1			6	DATA1	
		7	D2			7	A2	
		8	A2			8	DATA2	
		9	D3			9	A3	
		10	A3			10	DATA3	
		11	D4			11	A4	
		12	A4			12	DATA4	
		13	D5			13	A5	
		14	A5			14	DATA5	
		15	D6			15	Ab	
		16	A6			16	DATA6	
		17	D7			17	A	
		18	A/			18	DATA/	
		19	N.C			19	AX	
		20	AB			20	DATAS	
		21	N.C			21	AU	
		22	A9			22	DATA9	
		23	N.C			23	AIU	
		24	AIU			24	DATATU	
		25	IN.C			25	A11	

26	A11 26	DATA11
27	N.C 27	A12
28	A12 28	DATA12
29	N.C 29	A1 3
30	A13 30	DATA13
31	N.C 31	A1 4
32	A14 32	DATA14
33	N.C 33	A1 5
34	N.C 34	DATA1 5
35	N.C 35	A16
36	N.C 36	DATA16
37	N.C 37	A1 7
38	N.C 38	DATA17
39	N.C 39	A1 8
40	N.C 40	DATA18
41	N.C 41	A19
42	N.C 42	DATA19
43	N.C 43	A20
44	N.C 44	DATA20
45	N.C 45	A21
46	N.C 46	DATA21
47	N.C 47	A22
48	N.C 48	DATA22
49	N.C 49	A23
50	N.C 50	DATA23
51	N.C 51	A24
52	N.C 52	DATA24
53	N.C 53	A25
54	N.C 54	DATA25
55	N.C 55	LA DDR26
56	N.C 56	DATA26
57	N.C 57	NOE
58	nOE 58	DATA27
59	N.C 59	N WE
60	N WE 60	DATA28
61	N.C 61	NGCS3
62	N.C 62	DATA29
63	N.C 63	NGCS4
64	n GCS4 64	DATA30
65	N.C 65	NGCS5
66	N.C 66	DATA31
67	N.C 67	N RESET

		68	n RESET		68	NXDREQ0	
		69	N.C		69	NRSTOUT	
		70	N.C		70	NX DACK0	
		71	N.C		71	NWAIT	
		72	N.C		72	NXDREQ1	
		73	N.C		73	CLKOUTO	
		74	N.C		74	NXDACK1	
		75	N.C		75	OLKOUT1	
		76	N.C		76	BATTFLT	
		77	N.C		77	EXTCLK	
		78	N.C		78	PWREN	
		79	VDD5V		79	VDD5V	
		80	VDD5V		80	VDD5V	
		81	N.C		81	NWBE0	
		82	N.C		82	NWBE1	
		83	N.C		83	NWBE2	
		84	N.C		84	NWBE3	
		85	N.C		85	N.C	
		86	N.C		86	N.C	
		87	GND		87	GND	
		88	GND		88	GND	
		89	GND		89	GND	
		90	GND		90	GND	
JP2	HEADER 2×50	1	VDD5V	MAIN, J3	1	VDD5V	
		2	VDD5V	HEADER 2×50	2	VDD5V	
		3	N.C		3	INP1	
		4	N.C	 	4	GPJ0	
		5	N.C	 	5	INP2	
		6	N.C	 	6	GPJ1	
		7	N.C	 	7	INP3	
		8	N.C	 	8	GPJ2	
		9	N.C		9	INP4	
		10	N.C	 	10	GPJ3	
		11	N.C		11	INP5	
		12	N.C		12	GPJ4	
		13	N.C		13	INP6	
		14	N.C		14	GPJ5	
		15	N.C		15	INP7	
		16	N.C	 	16	GPJ6	
		17	N.C		17	INP8	
		18	N.C		18	GPJ7	

19	N.C 19	GPD0
20	N.C 20	GPJ8
21	N.C 21	GPD1
22	N.C 22	GPJ9
23	N.C 23	GPD2
24	N.C 24	GPJ10
25	N.C 25	GPD3
26	N.C 26	GPJ11
27	N.C 27	GPD4
28	N.C 28	GPJ12
29	N.C 29	GPD5
30	N.C 30	GPE0
31	N.C 31	GPD6
32	N.C 32	GPE1
33	N.C 33	GPD7
34	N.C 34	GPE2
35	N.C 35	OUTP1
36	N.C 36	GPE3
37	N.C 37	OUTP2
38	N.C 38	GPE4
39	N.C 39	OUTP3
40	N.C 40	GPE5
41	N.C 41	OUTP4
42	N.C 42	GPE6
43	N.C 43	OUTP5
44	N.C 44	GPE7
45	N.C 45	OUTP6
46	N.C 46	GPE8
47	N.C 47	OUTP7
48	N.C 48	GPE9
49	N.C 49	OUTP8
50	N.C 50	GPE10
51	GND 51	GND
52	GND 52	GND
53	VDD5V 53	VDD5V
54	VDD5V 54	VDD5V
55	N.C 55	GPA17
56	N.C 56	GPE11
57	N.C 57	GPA18
58	N.C 58	GPE12
59	N.C 59	GPA19
60	N.C 60	GPE13

61	N.C		31 GPA20
62	N.C		32 GPG5
63	N.C		33 GPA22
64	N.C		34 GPG6
65	N.C		35 HCON
66	N.C		6 GPG7
67	N.C		37 FRNB
68	N.C		38 NSS_KBD
69	N.C		39 LOGIC_EN
70	N.C		70 NDIS_OFF
71	N.C		71 EINT21
72	N.C		72 EINT19
73	N.C		73 EINT22
74	N.C		74 L3CLOCK
75	N.C		75 EINT23
76	N.C		76 L3DATA
77	N.C		77 USB_REC
78	N.C		78 L3MODE
79	N.C		79 LP0
80	N.C		30 NLRDATXDEN
81	N.C		31 LP1
82	L_LINK		32 KEY BOARD
83	N.C		33 LP2
84	RST		34 EINT6
85	N.C		35 LP3
86	EXT_CLK		36 IRQ_LAN
87	N.C		37 LP4
88	N.C		38 DMASTART
89	N.C		39 LP5
90	N.C		OMAMODE0
91	N.C)1 LP6
92	N.C		32 DMAMODE1
93	EINT3		3 ENC_CW
94	N.C		34 EINT3
95	N.C		95 ENC_CCW
 96	N.C)6 TXD0_BO
 97	N.C)7 ENC_DIR
 98	N.C		98 RXD0_BO
 99	GND		J9 GND
100	GND	1)0 GND

PCB - HEAD PCB



Part #; UVH-03

Main Function

1. Connected with Main PCB, send the signal for ink supply by transferring the signal received from each sub Ink Tank.

2. Send output data received by connecting with each cartridge PCB.

3. Receive Floating signal from each ink tank.

4. Receive the signal for Home sensor, size sensor and encoder.

5. Receive driving power from SUB PCB#2 thru core cable.

PCB – HEAD PCB



Part #; UVH-03

PCB – HEAD PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

HEAD F	РСВ						
J1	HOME	1	VDD5V		HOME SENSOR PCB	1	VDD5V(RED)
	5045-3P	2	SEN-HOME		5051-3P	2	SEN-HOME-OUT(YELLOW)
		3	GND			3	GND(BLACK)
.12	K	1	SIGNAL (BLACK)		FLOAT SENSOR, K	1	SIGNAL K(BLACK)
-	5268-2P	2	GND (BLACK)		5264-2P	2	GND(BLACK)
					0204 21		
.13	ENCODER	1	B ANGLE		ENCODER	1	ENC-B(YELLOW)
	GI-I GC4P	2	VDD5V		9740(180dpi)	2	5V(BED)
	ANGLE	3	A ANGLE		LGCONNECTOR	3	FNC-A(BLUE)
		4	GND			4	GND(BLACK)
14	<u>^</u>	1				1	
J4	5069_0D	0			FLOAT SENSON, C	0	
	3208-2F	2			5204-2F	2	GIND(BLACK)
15	м	1	SIGNAL M (BLACK)			1	SIGNAL M(BLACK)
00	5268_2D	2			5264-2D	2	
	5200-21	2	GIND (BLAGIV		5204 21	2	GIND(BLACK)
.16	v	1	SIGNAL Y (BLACK)		FLOAT SENSOR Y	1	SIGNAL Y (BLACK)
	5268-2P	2	GND (BLACK)		5264-2P	2	GND(BLACK)
					0204 21		
.17	SIZE	1	V-REE(+V) (YELLOW	()	SIZE SENSOR	1	V+(BLUE)
••	5268-4P	2	GND (BLACK)		5264-4P	2	GND(BLACK)
		3	SEN-SIZE-1 (YELLC	w)		3	OUT(YELLOW)
		4	VDD5V (RED)			4	5V+(RED)
10	10	1				1	
JO	5069 0D	0	SIGNAL LC (BLACK)		FLUAI SENSUR, LU	1	
	3208-2F	2			5204-2F	2	GIND(BLACK)
.19	LM	1	SIGNAL I M (BLACK)		FLOAT SENSOR, LM	1	SIGNAL I M(BLACK)
	5268-2P	2	GND (BLACK)		5264-2P	2	GND(BLACK)
J10	TEMP_SEN1	1	SEN1	NOT USED			
		2	GND	NOT USED			
J11	SPARE	1	SIGNAL SPARE	NOT USED			
	5268-2P	2	GND	NOT USED			
J12	SOLUTION	1	SIGNAL S (BLACK)		FLOAT SENSOR	1	SIGNAL-SOL(WHITE)
	5268-2P	2	GND (BLACK)	SOLUTION SUB INK TANK	SOLUTION	2	GND(BLACK)
.11.3	TEMP SEN2	1	SEN2	NOT LISED			
0.0	5268-2P	2	GND	NOT USED			
	5200 21	2	GIND	NOT OSED			
J14	HEATER POW	1	DC 24V	NOT USED			
	B2P-VH	2	CONTROL GND	NOT USED			
14 5			DOTAV				DO10V
115		1			1:1 CONNECT	I	
	-649-254D94 V	2			HPS_PCN10_	2	
	-043-234DSA K	3				3	
		4	DUIZV	1	04F-204DOA N	4	DUIZV

5	L h DATA1		5	L h DATA1
6	R h DATA1		6	R h DATA1
7	L h DATA2		7	L h DATA2
8	R h DATA2		8	R h DATA2
 9	L h DATA3		9	L h DATA3
10	B h DATA3	 	10	B h DATA3
 11	L h DATA4	 	11	L b DATA4
 12	B h DATA/	 	12	B b DATA4
 13		 	13	
 14			14	
 14			14	
 15			10	
 17			17	
 10			10	
 10	CTD2 I		10	
 19			19	STDOL I
 20	OND	 	20	
 21	GND	 	21	
 22	GND	 	22	
 23		 	23	
 24	ULK I	 	24	
 25	UPIL I	 	25	
 26	LOAD I		26	LOAD I
 27	DP2H I	 	27	
 28	LAI I		28	LAI I
 29	DP2L I	 	29	
 30	DADAT I		30	DADAT I
 31	D GNT I	 	31	D CIVIT I
 32	DACLK I	 	32	DACLK I
 33	AD SEL		33	AD SEL
 34	DALD I		34	DALD I
 35	SEN_HUME		35	SEN_HOME
 36	SEN_SIZE		36	SEN_SIZE
 37	ENC_A		37	ENC_A
 38	ENS_B		38	ENS_B
 39	GND		39	GND
 40	GND		40	GND
 41	ANO		41	ANO
 42	AN4		42	AN4
 43	AN1		43	AN1
 44	AN5		44	AN5
 45	AN2		45	AN2
 46	AN6	 	46	ANG
 47	AN3		47	AN3
 48	AN7	 	48	AN7
 49	GND		49	GND
 50	GND		50	GND
 51	INKL 1		51	INKL 1
 52	INKL 2		52	INKL 2
 53	INKL 3		53	INKL 3
 54	INKL 4		54	INKL 4
 55	INKL 5		55	INKL 5
56	INKL 6		56	INKL 6

		57	INKL 7		57	INKL 7	
		58	INKL 8		58	INKL 8	
		59	GND		59	GND	
		60	GND		60	GND	
		61	N.C.		61	N.C.	
		62	NC		62	NC	
		63	NC		63	NC	
		64	NC	 	64	NC	
		04	11.0		01	11.0	
.116	INK K	1	VH-POW	 CARTRIDGE PCB JZ	1	GND	
010	5597-30P	2	VH-POW	 5597-30P	2	GND	
	straight Type	3	VH-POW		3	STBCI	
	otraight 1990	4	GND	 	4		
		5	DC12V		5	STB3	
		6	GND		6	STB2	
		7			7	STB1	
		,			, 0	LAT	
		9			9		
		10			10		
		11			10		
		10			10		
		12			12		
		1.0			13		
		14			14		
		10			10		
		17			10		
		10		 	10		
		10		 	10	ADI	
		19		 	19	DA1	
		20		 	20	DAI	
		21		 	21	DP2L	
		22		 	22	DP2H	
		23			23	DPTL	
		24	SIBI	 	24		
		25	51B2		25	GND	
		26	SIB3		26	DCT2V	
		27			27	GND	
		28	SIBUL		28	VHPOW	
		29	GND		29	VHPOW	
		30	GND		30	VH-POW	
						0.10	
J1 /	INK_C	1	VH-POW	CARTRIDGE PCB, J/	1	GND	
	5597-30P	2	VH-POW	5597-30P	2	GND	
	straight lype	3	VH-POW		3	STBCL	
		4	GND		4	LOAD	
		5	DC12V	 	5	S1B3	
		6	GND	 	6	STB2	
		7	DETH	 	7	SIB1	
		8	DP1L	 	8	LAI	
		9	DP2H	 	9	CLK	
		10	DP2L	 	10	R-DAT1	
		11	DA1 (C)	 	11	L-DAT1	
		12	DA2(C)		12	R-DAT0	

		13	AD1(C)		13	L-DAT0	
		14	GND		14	GND	
		15	VDD5V		15	VDD5V	
		16	VDD5V		16	VDD5V	
		17	GND		17	GND	
		18	I-DATO(C)	i	18	AD1	
		19	B-DATO(C)		19	DA2	
		20	I -DAT1(C)	i	20	DA1	
		21	I -DAT1 (C)		21	DP2I	
		22	CI K		22	DP2H	
		23	LAT	i	23	DP1I	
		24	STB1		24	DP1H	
		25	STB2	i	25	GND	
		26	STB3		26	DC12V	
		27	LOAD		27	GND	
		28	STBCI		28	VH-POW	
		29	GND		29	VH-POW	
		30	GND		30	VH-POW	
J18	INK M	1	VH-POW	CARTRIDGE PCB. JZ	1	GND	
	5597-30P	2	VH-POW	5597-30P	2	GND	
	straight Type	3	VH-POW		3	STBCI	
		4	GND		4		
		5	DC12V		5	STB3	
		6	GND		6	STB2	
		7	DP1H		7	STB1	
		8	DP1I		8	LAT	
		9	DP2H		9	CLK	
		10	DP2I		10	B-DAT1	
		11	DA1(M)		11	I –DAT1	
		12	DA2(M)	i	12	B-DAT0	
		13	AD1 (M)		13	I -DATO	
		14	GND	i	14	GND	
		15	VDD5V		15	VDD5V	
		16	VDD5V	i	16	VDD5V	
		17	GND		17	GND	
		18	L-DAT0(M)		18	AD1	
		19	R-DATO(M)		19	DA2	
		20	L-DAT1 (M)		20	DA1	
		21	L-DAT1(M)		21	DP2L	
		22	CLK		22	DP2H	
		23	LAT		23	DP1L	
		24	STB1		24	DP1H	
		25	STB2		25	GND	
		26	STB3		26	DC12V	
		27	LOAD		27	GND	
		28	STBCL		28	VH-POW	
		29	GND		29	VH-POW	
		30	GND		30	VH-POW	
J19	INK_Y	1	VH-POW	CARTRIDGE PCB. J7	1	GND	
	5597-30P	2	VH-POW	5597-30P	2	GND	

	straight Type	3	VH-POW		3	STBCL	
		4	GND		4	LOAD	
		5	DC12V		5	STB3	
		6	GND		6	STB2	
		7	DP1H		7	STB1	
		8	DP1I		8	LAT	
		9	DP2H		9	CLK	
		10	DP2I		10	R-DAT1	
		11	DA1(Y)		11	I -DAT1	
		12	DA2(Y)		12	R-DAT0	
		13	AD1(Y)		13	I -DATO	
		14	GND		14	GND	
		15	VDD5V		15	VDD5V	
		16	VDD5V		16	VDD5V	
		17	GND		17	GND	
		18	I - DATO(Y)		18	AD1	
		19	B-DATO(Y)		19	DA2	
		20	I - DAT1(Y)		20	DA1	
		21	I - DAT1(Y)		21	DP2I	
		22	CLK		22	DP2H	
		23	LAT		23	DP1I	
		24	STB1		24	DP1H	
		25	STB2		25	GND	
		26	STB3		26	DC12V	
		27			27	GND	
		28	STBCI		28	VH-POW	
		29	GND		29	VH-POW	
		30	GND		30	VHPOW	
					00		
.120	POWER CON	1	DC24V	SUB#2 PCB	1	DC24V	
	6P	2	DC24V	POWER CON 6P	2	DC24V	
		3	VHPOW		3	VHPOW(FIRE-HV)	
		4	VHPOW		4	VHPOW(FIRE-HV)	
		5	GND		5	GND	
		6	GND		6	GND	
J21	INK LC	1	VH-POW	CARTRIDGE PCB. J7	1	GND	
-	5597-30P	2	VH-POW	5597-30P	2	GND	
	straight Type	3	VH-POW		3	STBCL	
		4	GND		4	LOAD	
		5	DC12V		5	STB3	
		6	GND		6	STB2	
		7	DP1H		7	STB1	
		8	DP1L		8	LAT	
		9	DP2H		9	CLK	
		10	DP2L		10	R-DAT1	
		11	DA1 (LC)		11	L-DAT1	
		12	DA2(LC)		12	R-DAT0	
		13	AD1 (LC)		13	L-DAT0	
		14	GND		14	GND	
		15	VDD5V		15	VDD5V	
		16	VDD5V		16	VDD5V	

		17 GND		17	GND
		18 L-DAT0(LC)		18	AD1
		19 R-DAT0(LC)		19	DA2
		20 L-DAT1(LC)		20	DA1
		21 L-DAT1(LC)		21	DP2L
		22 CLK		22	DP2H
		23 LAT		23	DP1L
		24 STB1		24	DP1H
		25 STB2		25	GND
		26 STB3		26	DC12V
		27 LOAD		27	GND
		28 STBCL		28	VH-POW
		29 GND		29	VH-POW
		30 GND		30	VH-POW
J22	INK_LM	1 VH-POW	CARTRIDGE PCB, J7	1	GND
	5597-30P	2 VH-POW	5597-30P	2	GND
	straight Type	3 VH-POW		3	STBCL
		4 GND		4	LOAD
		5 DC12V		5	STB3
		6 GND		6	STB2
		7 DP1H		7	STB1
		8 DP1L		8	LAT
		9 DP2H		9	CLK
		10 DP2L		10	R-DAT1
		11 DA1(LM)		11	L-DAT1
		12 DA2(LM)		12	R-DAT0
		13 AD1(LM)		13	L-DAT0
		14 GND		14	GND
		15 VDD5V		15	VDD5V
		16 VDD5V		16	VDD5V
		17 GND		17	GND
		18 L-DAT0(LM)		18	AD1
		19 R-DAT0(LM)		19	DA2
		20 L-DAT1(LM)		20	DA1
		21 L-DAT1(LM)		21	DP2L
		22 CLK		22	DP2H
		23 LAT		23	D01L
		24 STB1		24	DP1H
		25 STB2		25	GND
		26 STB3		26	DC12V
		27 LOAD		27	GND
		28 STBCL		28	VH-POW
		29 GND		29	VH-POW
		30 GND		30	VH-POW

PCB - REFILL PCB



Part #; UVR-03

MAIN FUNCTION

- 1. Connected to both SUB PCB 2 and Communication port.
- 2. Control each ink pump
- By connecting with CONTROL PCB.
 Send and receive the status of Ink and Ink supplying and signal of ink supplying
- 4. By checking the remained ink in the Main Ink Tank, Sound Biff buzzer if ink is short.
- 5. Set task up motor controller and overflow.

PCB - REFILL PCB



Part #; UVR-03

CONNECTOR CONNECTION MAP

J1 B2P-VH --> Pump LC J2 5267-3 --> Level Sensor M J3 B2P-VH --> Pump M J4 5267-3 --> Level Sensor K J6 5267-3 --> Level Sensor LC J5 B2P-VH --> Pump K J8 Disconnection J10 5566-2 --> Before Task up motor J11 5219-2 --> After Task Up Motor J14 B2P-VH --> SMPS#4 DC24V J15 5566-4 --> Before Task up motor J16 5219-3 --> After Task Up Motor J18 Disconnection J17 5267-3 --> SUB J9 J19 5045-4 --> SUB J18 J20 B2P-VH --> Pump S J21 5267-3 --> Level Sensor Y J22 5267-2 --> Level Sensor C J23 5267-3 --> Level Sensor LM J24 B2P-VH --> Pump LM J25 B2P-VH --> Pump Y J26 B2P-VH --> Pump C J27 B2P-VH --> Pump W (Disconnection) J28 B2P-VH --> Level Sensor S J29 5267-3 --> Level Sensor W (Disconnection) J30 Disconnection J32 Disconnection J31 IDC30 --> Control J18 J34 Disconnection J35 Disconnection J37 5267-4 --> BUZZER

PCB – REFILL PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

REFILL									
J1	PUMP_LC	1	INK_PUMP_LC(BROWN)		INK PUMP LC	MOTOR -			
	B2P-VH	2	DC24V(GREEN)			MOTOR +			
J2	TANK_M	1	GND		TANK M Level sensor	BLACK	COMMON		
	5267-3P	2	E_TANK_M			RED	EMPTY SENSOR		
		3	F_TANK_M			YELLOW	FULL SENSOR		
J3	PUMP_M	1	INK_PUMP_M(BROWN)		INK PUMP M	MOTOR -			
	B2P-VH	2	DC24V(RED)			MOTOR +			
J4	TANK_K	1	GND		TANK K Level sensor	BLACK	COMMON		
	5267-3P	2	E_TANK_K			RED	EMPTY SENSOR		
		3	F_TANK_K			YELLOW	FULL SENSOR		
J5	PUMP_K	1	INK_PUMP_K(BROWN)		INK PUMP K	MOTOR -			
	B2P-VH	2	DC24V(BLACK)			MOTOR +			
J6	TANK_LC	1	GND		TANK LC Level sensor	BLACK	COMMON		
	5267-3P	2	E_TANK_LC			RED	EMPTY SENSOR		
		3	F_TANK_LC			YELLOW	FULL SENSOR	 	
J8	LAMP	1	DC24V(LAMP+)	NOT USED					
	5045-2P	2	LAMP-	NOT USED				 	
J10	F_MOTOR	1	U1-Q1(BROWN)		TAKE UP MOTOR FRONT			 	
	5566-2P	2	U1-Q2(BLUE)					 	
J11	R_MOTOR	1	U1-Q3(BROWN)		TAKE UP MOTOR REAR			 	
	5219-2P	2	U1-Q4(BLUE)					 	
J1 4	POWER	1	GND(BLACK)		SMPS, WK120S24AR	1	DC24V(RED)		
	B2P-VH	2	DC24V(RED)		(DC24V5A)	2			
						3	GND(BLACK)		
						4			

J15	TAKE-F-SEN	1	TAKE-F-SEN(BLACK)		AUTONICS, PHOTOSENSOR	BROWN	DC24V		
	5566-4P	2	GND(BLUE)			BLACK	SENSOR OUT		
		3	N.C			BLUE	GND		
		4	DC24V(BROWN)						
J16	TAKE_R_SEN	1	DC24V(BROWN)		AUTONICS, PHOTOSENSOR	BROWN	DC24V		
	5219-3P	2	TAKE-R-SEN(BLACK)			BLACK	SENSOR OUT		
		3	GND(BLUE)			BLUE	GND		
J17	RS_REFILL	1	RX REFILL		SUB J9 (TAKEUP/REFILL)	1	+5V		
	5267-3P	2	TX REFILL		5267-4P		2 TX DATA(RED)	 	
		3	GND			3	B RX DATA(BLUE)	 	
						4	GND(YELLOW)	 	
J18	TAKEUP	1	GND	NOT USED				 	
	HIF3BA16DSA	2	+5V	NOT USED				 	
		3	GND	NOT USED				 	
		4	+5V	NOT USED				 	
		5	N.C	NOT USED				 	
		6	N.C	NOT USED				 	
		7	N.C	NOT USED				 	
		8	N.C	NOT USED				 	
		9	DIR_CW_SW	NOT USED				 	
		10	CW_LED	NOT USED				 	
		11	DIR_CCW_SW	NOT USED				 	
		12	CCW_LED	NOT USED				 	
		13	AUTO_SW	NOT USED				 	
		14	AUTO_LED	NOT USED				 	
		15	ERROR_SW	NOT USED				 	
		16	ERROR_LED	NOT USED				 	
J19	FOOT SW	1	+5V(WHITE)		SUB J18 (SOL_ON)	1	VDD5V(WHITE)	 	
	5045-4P	2			5267-3P	2	2	 	
		3				3	B SOL_ON(BLACK)	 	
		4	FOOT_SOL_SW(BLACK)						

J20	SOL_PUMP	1	INK_PUMP_SOL(BROWN)		INK PUMP SOL		MOTOR -		
	B2P-VH	2	DC24V(WHITE)				MOTOR +		
J21	TANK_Y	1	GND		TANK_Y Level sensor	BLACK	COMMON		
	5267-3P	2	E_TANK_Y			RED	EMPTY SENSOR		
		3	F_TANK_Y			YELLOW	FULL SENSOR		
J22	TANK_C	1	GND		TANK_C Level sensor	BLACK	COMMON		
	5267-3P	2	E_TANK_C			RED	EMPTY SENSOR		
		3	F_TANK_C			YELLOW	FULL SENSOR		
J23	TANK_LM	1	GND		TANK_LM Level sensor	BLACK	COMMON		
	5267-3P	2	E_TANK_LM			RED	EMPTY SENSOR		
		3	F_TANK_LM			YELLOW	FULL SENSOR		
J24	LM_PUMP	1	INK_PUMP_LM(BROWN)		INK PUMP LM	MOTOR -			
	B2P-VH	2	DC24V(ORANGE)			MOTOR +			
J25	Y_PUMP	1	INK_PUMP_Y(BROWN)		INK PUMP Y	MOTOR -			
	B2P-VH	2	DC24V(YELLOW)			MOTOR +			
J26	C_PUMP	1	INK_PUMP_C(BROWN)		INK PUMP C	MOTOR -			
	B2P-VH	2	DC24V(BLUE)			MOTOR +		 	
J27	W PUMP	1	INK_PUMP_W (BROWN)		INK PUMP W	MOTOR -			
	B2P-VH	2	DC24V(WHITE/YELLOW)			MOTOR +		 	
J28	TANK_SOL	1	GND		TANK_SOL Level sensor	BLACK	COMMON	 	
	5267-3P	2	E_TANK_SOL			RED	EMPTY SENSOR	 	
		3	F_TANK_SOL			YELLOW	FULL SENSOR		
J29	W TANK	1	GND	NOT USED					
	5267-3P	2	E_TANK_W	NOT USED					
		3	F_TANK_W	NOT USED					

J30	OVERFLOW	1	+5V	NOT USED					
	5267-2P	2	OVER_FLOW	NOT USED					
J31	CONTROL	1	SW Y		CONTORL J18	1	SW Y		
	HIF3BA30DSA	2	SW M		HIF3BA30DS	2	SW M		
		3	SW C			3	SW C		
		4	SW K			4	SW K		
		5	SW_LM			5	SW_LM		
		6	SW_LC			6	SW_LC		
		7	SW_W			7	SW_W		
		8	MANUAL_SOL_SW			8	MANUAL_SOL_SV	V	
		9	+5V			9	+5V		
		10	GND			10	GND		
		11	F_LED_Y			11	F_LED_Y		
		12	F_LED_M			12	F_LED_M		
		13	F_LED_C			13	F_LED_C		
		14	F_LED_K			14	F_LED_K		
		15	F_LED_LM			15	F_LED_LM		
		16	F_LED_LC			16	F_LED_LC		
		17	F_LED_W			17	F_LED_W		
		18	F_LED_SOL			18	F_LED_SOL		
		19	+5V			19	+5V		
		20	GND			20	GND		
		21	E_LED_Y			21	E_LED_Y		
		22	E_LED_M			22	E_LED_M		
		23	E_LED_C			23	E_LED_C		
		24	E_LED_K			24	E_LED_K		
		25	E_LED_LM			25	E_LED_LM		
		26	E_LED_LC			26	E_LED_LC		
		27	E_LED_W			27	E_LED_W		
		28	E_LED_SOL			28	E_LED_SOL		
		29	+24V			29	+24V		
		30	GND			30	GND		
J32	AIR_TANK_SEN	1	+5V	NOT USED					
	5267-6P	2		NOT USED					
		3	PRESSURE LOW	INOT USED					
		4	N.C	NOT USED					
		5	N.C	NOT USED					
		6	N.C	INO I USED					

J34	MAIN_ERROR	1	MAIN_ERROR	NOT USED					
	5267-3P	2	N.C	NOT USED					
		3	GND	NOT USED					
J35	SOL_VALVE	1	SOL_VALVE	NOT USED					
	B2P-VH	2	DC24V	NOT USED					
J37	BUZZER	1	GND		DC5V용 BUZZER	BLACK	BUZZER -		
	5267-4P	2							
		3							
		4	BUZZER			RED	BUZZER +		

PCB – CARTRIDGE#1 PCB



MAIN FUNCTION

Connected with Signal connector Coming from HEAD PCB.

Part #; UVC-03

PCB – CARTRIDGE#1 PCB



- J7 5597-30 Straight --> Head J16 K
 - --> Head J17 C
 - --> Head J18 M
 - --> Head J19 Y
 - --> Head J21 LC
 - --> Head J22 LM



Part #; UVC-03

PCB – CARTRIDGE#1 PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

PCB – CARTRIDGE IO MAP-1

С	artridge PCB				
				Head PCB	
J7	1	GND	J16	1	VH-POW
5597-30P	2	GND	5597-30P	2	VH-POW
straight Type	3	STBCL	straight Type	3	VH-POW
	4	LOAD		4	GND
	5	STB3		5	DC12V
	6	STB2		6	GND
	7	STB1		7	DP1H
	8	LAT		8	DP1L
	9	CLK		9	DP2H
	10	R-DAT1		10	DP2L
	11	L-DAT1		11	DA1
	12	R-DAT0		12	DA2
	13	L-DATO		13	AD1
	14	GND		14	GND
	15	VDD5V		15	VDD5V
	16	VDD5V		16	VDD5V
	17	GND		17	GND
	18	AD1		18	L-DATO
	19	DA2		19	R-DAT0
	20	DA1		20	L-DAT1
	21	DP2L		21	L-DAT1
	22	DP2H		22	CLK
	23	DP1L		23	LAT
	24	DP1H		24	STB1
	25	GND		25	STB2
	26	DC12V		26	STB3
	27	GND		27	LOAD
	28	VH-POW		28	STBCL
	29	VH-POW		29	GND
	30	VH-POW		30	GND
PCB – CARTRIDGE IO MAP-2

J9	1	VH	Print Head	1	VH	
5077-50P	2	N.C		2	N.C	
Receptacle	3	N.C		3	N.C	
	4	R-COM24		4	R-COM24	
	5	R-COM24		5	R-COM24	
	6	R-COM24		6	R-COM24	
	7	R-COM13		7	R-COM13	
	8	GND		8	GND	
	9	R-COM13		9	R-COM13	
	10	L-SI1		10	L-SI1	
	11	L-SI0		11	L-S10	
	12	TH		12	ТН	
	13	R-STB3		13	R-STB3	
	14	VDD5V		14	VDD5V	
	15	R-STB2		15	R-STB2	
	16	GND		16	GND	
	17	R-STB1		17	R-STB1	
	18	GND		18	GND	
	19	R-STBCL		19	R-STBCL	
	20	GND		20	GND	
	21	R-CLK		21	R-CLK	
	22	GND		22	GND	
	23	R-LAT		23	R-LAT	
	24	GND	 	24	GND	
	25	R-LOAD		25	R-LOAD	
	26	L-LOAD	 	26	L-LOAD	
	27	GND	 	27	GND	
	28	L-LAT	 	28	L-LAT	
	29	GND	 	29	GND	
	30	L-CLK		30	L-CLK	
	31	GND	 	31	GND	
	32	L-STBCL	 	32	L-STBCL	
	33	GND		33	GND	

PCB – CARTRIDGE IO MAP-3

34 L-	STB1	34	L-STB1	
35 VI	DD5V	35	VDD5V	
36 L-	-STB2	36	L-STB2	
37 Tł	H	37	TH	
38 L-	-STB3	38	L-STB3	
39 R	R–SI1	39	R-SI1	
40 R	R-SI0	40	R-S10	
41 G	AND	41	GND	
42 L-	-COM13	42	L-COM13	
43 L-	-COM13	43	L-COM13	
44 L-	-COM13	44	L-COM13	
45 L-	-COM13	45	L-COM13	
46 L-	-COM13	46	L-COM13	
47 L-	-COM13	47	L-COM13	
48 N	I.C	48	N.C	
49 N	I.C	49	N.C	
50 VI	Ή	50	VH	

PCB – CARTRIDGE#2 PCB



Part #; UVC-03

MAIN FUNCTION

- 1. Voltage Control Terminal for left side channel. (TP1, TP2)
- 2. Voltage Control Volume for left side channel. (VR1, VR2)
- 3. Left Channel Signal Process.

PCB – CARTRIDGE#2 PCB



Part #; UVC-03

CONNECTOR CONNECTION MAP

- JP1 : (RED) LEFT CHANNEL HIGH 15.00V Setting terminal.
- JP2 : (YEL) LEFT CHANNEL LOW 7.50V Setting terminal.
- JP3 : (BLACK) GND TERMINAL.
- VR1 : (LH) LEFT CHANNEL HIGH 15.00V Setting volume.
- VR2 : (LL) LEFT CHANNEL LOW 7.50V Setting volume.

PCB – CARTRIDGE#2 PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

PCB – Cartridge#3 PCB



Part #; UVC-03

MAIN FUNCTION

- 1. Voltage Control Terminal for Right side channel. (TP1, TP2)
- 2. Voltage Control Volume for Right side channel. (VR31, VR4)
- 3. Right Channel Signal Process.

PCB – CARTRIDGE#3 PCB



CONNECTOR CONNECTION MAP

JP4 : (RED) RIGHT CHANNEL HIGH 15.00V SETTING TERMINAL JP5 : (YEL) RIGHT CHANNEL LOW 7.50V SETTING TERMINAL. JP6 : (BLA) GND TERMINAL. VR3 : (RH) RIGHT CHANNEL HIGH 15.00V SETTING VOLUME VR4 : (RL) RIGHT CHANNEL LOW 7.50V SETTING VOLUME

Part #; UVC-03

PCB – CARTRIDGE#3 PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

PCB – CARTRIDGE#4 PCB



MAIN FUNCTION

Connected with Konica HEAD

Part #; UVC-03

PCB – CARTRIDGE#4 PCB



Part #; UVC-03

CONNECTOR CONNECTION MAP

J7 5077-50 Receptacle --> Print Head K

- --> Print Head C
- --> Print Head M
- --> Print Head Y
- --> Print Head LC
- --> Print Head LM

PCB – CARTRIDGE#4 PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

PCB - HEAD LIFT PCB



Part #; UVL-01

Main Function

- 1. Connect Step Motor Connector with Headbase spring PCB1.
- 2. Transfer Input Signal of both Headbase temperature sensor and Sub-Ink temperature sensor to I/F PCB.
- 3. Receive the signal pf Headbase Header and sub ink tank heater from I/F OCB.
- 4. Input two sensors for sensing the Media
- 5. Output two Solenoids for function operation.
- 6. Connect with Purge Switch and Solenoid valve of Negative Pressure Purge Change.
- 7. Receive Driving Power from SMPS#2.

PCB - HEAD LIFT PCB



Part #; UVL-01

CONNECTOR CONNECTION MAP

- J1 5045-5 --> UP/DOWN Photo Sensor Omron
- J3 Disconnection
- J4 GIL-G4 --> Sub#2 J25
- J6 B5P-VH --> VT301/VT301V 3Ways Sol Valve
- J7 5045-9 --> I/F J2
- J8 B6P-VH --> I/F J1
- J10 5267-3 --> Temperature Sensor in Sub Ink Tank
- J11 Disconnection
- J12 B2P-VH --> Purge Switch
- J13 Disconnection
- J14 B3P-VH --> Heater of Sub Ink Tank
- J16 Disconnection
- J17 5267-4 --> Headbase Temperature Sensor
- J18 B4P-VH --> SMPS#2 DC24V
- J23 B7P-VH --> UP/DOWN (Big) & LOCK/UNLOCK (Small) Solenoid
- J25 5566-2 --> Headbase Heater
- CN3 5045-4 --> Stepping Motor

PCB - HEAD LIFT PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

PCB – HEAD LIFT IO MAP-1

HEAD	BASE LIFT									
J1	LIMIT_SEN	1	GND(BLACK)		SEN DOWN	1	+(RED)			
	5045-5P	2	24+V(RED)		OMRON EE-1001	2	L(RED)			
		3	DOWN SENSOR(WHITE)			3	OUT(WHITE)			
		4	UPSENSOR(WHITE)			4	-(BLACK)			
		5	N.C							
					SEN UP		5559-4P		5557-4P	
					OMRON EE-1001	1	(BLACK)	1	(BLACK)	1
						2	(RED)	2	(RED)	2
						3	(WHITE)	3	(WHITE)	3
						4		4		4
J3	AVR_WRITE			NOT USED						
.14	PC BS232	1	GND(BLACK BED)	GORE CABLE	SUB PCB J6	1	GND(BLACK BED)			
	GII G-4	2	BX DATA(OBANGE OBANGE BAND)		(FEED)	2	BXD(BBOWN BBC			
		3	TX DATA(BROWN, BROWN BAND)		5045-4	3	TXD(OBANGE.OB	ANGE BAND)	
		4	N.C			4	N.C		Í	
.16	3WAY VALVE	1	GND			1	MALE	1	FEMALE	
	B5P-VH	2	SOL			2	SMP-04V-NC	2	SMR-0V-N	
	20	3	1002				0			
		4	GND			3		3		
		5	SOL			4		4		
17	SEN	1	N C(SPEAR A)			1	DOE N.C.			
57	5045-0P	2	N.C(SPEAR B)		5045-8P	2	TV NC			
	0040 01	2			5045 01	2	DASE D'(ODANICE			
		0					BASE B (ORANGE	DAND)		
		4				4	BASE B(URANGE)			
<u> </u>		0				5		AND)		
		0				0	SUB B (BROWN)			
		/	BASE A(BROWN BAND)			/	SUB B(RED)			
		8				8	SUB A(BLACK)			
		9	BASE B (ORANGE BAND)							
J8	POWER	1	DC24V(BLACK)	GORE CABLE	I/F PCB, J1	1	SUB HEATER(WH	(F)		
	B6P-VH	2	DC24V(BBOWN)		B6P-VH	2	BASE HEATER(GR	FFN)		
	20	3	GND(RED)			3	GND(YELLOW)			
		4	GND(YELLOW)			4	GND(RED)			
		5	BASE HEATER(GREEN)			5	DC24V(BBOWN)			
		6	SIB HEATER(WHITE)			6	DC24V(BLACK)			
						0	DOL IN DE KORY			
J10	SUB	1	SUB B'(WHITE)							
	5267-3P	2	SUB B(WHITE)		PT100Q, SUB INKTA	NK SEN	SOR			
		3	SUB A(RED)							
-										

PCB – HEAD LIFT IO MAP-2

J11	PSE531	1	PSE <in+>(BLACK)</in+>	NOT USED						
	5045-3P	2	DC24V(BROWN)	NOT USED	PSE531, Pressur	re Sensor				
		3	GND(BLUE)	NOT USED					1	
									1	
J12	PURGE SWITCH	1	DC24V(흑)		eao SWITCH		COM(흑)		1	
	B2P-VH	2	SOL(백)				NO(백)		1	
J13	ITV 201C	1	ITV(OUT+)(백)	NOT USED					1	
	5045-4P	2		NOT USED	ITV 2010				1	
		3	DC24V(갈)	NOT USED					1	
		4	GND(청)	NOT USED						
J16	ITV	1	ITV(OUT+)	NOT USED	ITV PCB				1	
	5045-10P	2	ITV(OUT+)	NOT USED	GORE CABLE					
		3	PSE(IN+)	NOT USED						
		4	PSE(IN+)	NOT USED						
		5	GND	NOT USED						
		6	GND	NOT USED						
		7	GND	NOT USED						
		8	DC24V	NOT USED						
		9	DC24V	NOT USED						
		10	DC24V	NOT USED						
J17	BASE	1	SUB B'(WHITE)							
	5267-4P	2	SUB B(WHITE)		PT100Q, HEADB	ASE SENSO	R			
		3								
		4	SUB A(RED)							
J18	LIFT_POWER	1	GND5V(BLACK)	GORE CABLE	SMPS#2	+(RED)				
	B4P-VH	2	DC5V(RED)		WK75S0524	-(BLACK)	DOSV(CITT)			
		3	GND24V(GREEN)			+(WHITE)				
		4	DC24V(WHITE)			-(GREEN)	DOZ4V(OIE)			
J23	LIFT_SOL	1	DC24V(BLACK)				5559-6P		5557-6P	
	B7P-VH	2				1	DC24V(BLACK)	1	(RED)	SOL#1
		3	SOL#1(RED)(UP/DOWN SOL)			2	SOL#1 (RED)	2	(RED)	<up dow<="" td=""></up>
		4				3	DC24V(YELLOW)	3	(RED)	SOL#2
		5	DC24V(YELLOW)			4	SOL#2(GREEN)	4	(RED)	<lock td="" un<=""></lock>
		6				5		5		
		7	SOL#2(GREEN)(LOCK/UNLOCK SOL)			6		6		
J25	BASE_H	1	GND(BLACK)				5557-2P		5559-2P	
L	5566-2P	2	BASE_HEATER(RED)			1	(BLACK)	1	(BLACK)	1
						2	(RED)	2	(RED)	2
										1
										2

PCB – HEAD LIFT IO MAP-3

CN3	STEP_MOTOR	1	A(BLUE)	STEPPING	1	(BLUE)		
	5045-4P	2	2 A'(RED)	MOTOR		N.C(WHITE)		
		3	B (GREEN)		2	(RED)	\frown	
		4	B'(BLACK)		3	(GREEN)	(M)	
						N.C(YELLOW)	\square	
					4	(BLACK)		

PCB - SUB PCB



Main Function

- 1. Control all kinds of I/O by connecting with Main PCB. (15pins core cable)
- Communicated with each device by built-in communication port (Servo-driver, Lifting. Refilling)
- 3. Input and output signal Procedure of UV Lamp, All kinds of sensors Input, and Motor and valve control
- 4. Receive driving power from SMPS#3.

Part #; UVS-03

PCB – SUB PCB



Part #; UVS-03

CONNECTOR CONNECTION MAP

J1 Disconnection J2 5267-3> Capping Cover
J3 Disconneciton J4 5267-2> Waste Sensor (Purge)
J5 GIL-G3> UV LAMP READY (Lamp PLC)
J6 5045-4> LIFT J4
J7 B6P-VH> LAMP SHUTTER (Lamp PLC)
J8 B8P-VH> SMPS\$3 J2 DC Power
J9 5267-4> Refill J17
J10 B4P-VH> SMPS#2 24VPower
J11 5267-8> LCD Board J1
J12 POWER CON 6P> HeadJ20
J13 Disconneciton J14 35313-2> Solenoid Valve
J15 B3P-VH> VT301Valve
J16 D-SUB 15P> Main JP3
J17 5267-12> Carriage Driver CN1B
J18 5267-3> Refill J19
J19 B2P-VH> Home Cover Solenoid Valve
J20 Disconnection J21 Disconnection
J22 5045-2> Carriage Driver CN1B
J23 5267-7> Sensor #2 SEN OUT
J24 5267-6> Home Cover Open/Cruse sensor
J25 5267-2> Sub Solution Tank #2

- J26 35312-2 --> Air LOW Sensor
- J27 35313-4 --> Capping / Section motor
- J28 5267-7 --> Carriage Servo CN3
- J29 5267-8 --> Feed servo CN3
- JP1 Servo Driver communication method selection
- 1-2 RS232 Selected
- 2-3 RS422 Selected

PCB – SUB PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

		3	N.C	NOT USED				
		4	GND	NOT USED	AVR			
		5	RESET	NOT USED	(WRITER)			
		6	GND	NOT USED				
		7	SCK	NOT USED				
		8	GND	NOT USED				
		9	MISO	NOT USED				
		10	GND	NOT USED				
J2	CAPPING_COVER	1	VDD5V (RED)		CAPPIG CLOSE SENSOR	BROWN	I VDD5V	
	5267-3P	2	CAPPING_COVER(WHITE)			BLACK	SENSOR OU	Γ
		3	GND(BLACK)			BLUE	GND	
J3	CARRIAGE	1	VDD5V	NOT USED				
	35312-4P	2	TX0_T2	NOT USED				
		3	TX0_R2	NOT USED				
		4	GND	NOT USED				
J4	WASTE INK1	1	WASTE INK1(WHITE)		WASTE TANK PURGE	ORANG	E	
		2	GND(BLACK)		FLOAT SENSOR	BROWN	1	
15		1						
00		2	LIV LAMP READY (WHITE)	NOT OOLD	OVERMIT IST CONNECTOR	PIN No1		ΞΔΠΥ
		3	GND(BLACK)			PIN No9	PLC GND	
10								
10		1						
	5045-4P	2	TXU_RI(BROWN, BROWN BA		GIL-G4	2		<u>-,URANGE BANL</u>
		4	VDD5V	NOT USED		4	N.C	
J7	LAMP/SHUTTER	1	DC 24V(RED)		UVLAMP 15P CONNECTOR	SELECT	SWITCH DC 2	4V (RED)
	B6P-VH	2	SHUTTER LEFT(BLACK)			PIN No6	; LEFT SHUTTE	R (BLACK)
		3	Shutter Right(White)			PIN No5	5 RIGHT SHUTT	ER (WHITE)

J7	LAMP/SHUTTER	1 DC 24V(RED)		UVLAMP 15P CONNECTOR	SELECT	SWITCH DC 24V	(RED)
	B6P-VH	2 SHUTTER LEFT(BLACK)			PIN Not	SLEFT SHUTTER (BLACK)
		3 SHUTTER RIGHT(WHITE)			PIN No5	FIGHT SHUTTER	(WHITE)
		4 UV LAMP OUT1					
		5 UV LAMP OUT2(GREEN/YELLC)W)		UV LAM	P SELECT SWTCH	I (GREEN/YE
		6 TEMP OUT					
J8	PWRIN	1 VDD5V (RED)		SMPS#3 J2	1	HIGH_VOLT_EN (GRAY)
	B8P-VH	2 GND (BLACK)			2	FIRE_HV (BROW	N)
		3 DC12V (YELLOW)			3	GND (WHITE)	
		4 GND (GREEN)			4	DC24V (ORANGE	=)
		5 DC24V (ORANGE)			5	GND (GREEN)	
		6 GND (WHITE)			6	DC12V (YELLOW	/)
		7 HIGH_VOLT_EN (GRAY)			7	GND (BLACK)	
		8 FIRE_HV (BROWN)			8	VDD5V (RED)	
J9	TAKEUP/REFILL	1 VDD5V	NOT USED	REFILL J17			
	5267-4P	2 RX0_T2 (RED)		5267-3P	1	RX REFILL (RED))
		3 RX0_R2 (WHITE)			2	TX REFILL (WHIT	E)
		4 GND (BLACK)			3	GND (BLACK)	
J10	POWER 24V	1 DC24V (WHITE)		SMPS#2	RED	DC5V	
	B4P-VH	2 DC24V			BLACK	5V GND	
		3 GND			WHIT	DC24V (WHITE)	
		4 GND (BLACK)			GREEN	24V GND (BLAC	$\langle \rangle$
J11	KEY/LCD	1 DC24V (BROWN)		LCD BOARD	1	DC24V (BROWN)
	5267-8P	2 DC24V (BROWN BAND)		5267-8P	2	DC24V (BROWN	BAND)
		3 VDD5V (ORANGE)			3	VDD5V (ORANGE	<u>=)</u>
		4 VDD5V (ORANGE BAND))			4	VDD5V (ORANGE	BAND))
		5 RX2 (GREEN)			5	RX2 (GREEN)	
		6 TX2 (GREEN BAND)			6	TX2 (GREEN BA	ND)
		7 GND (BLUE)			7	GND (BLUE)	
		8 GND (BLUE BAND)			8	GND (BLUE BAN	D)

J12	HI_POWER_HEAD	1	DC24V(GREEN)		HEAD J20	1	DC24V(GREEN)
	POWER CON 6P	2	DC24V (YELLOW)		POWER CON 6P	2	DC24V (YELLOW)
		3	FIRE_HV (BROWN)			3	FIRE_HV (BROWN)
		4	FIRE_HV (RED)			4	FIRE_HV (RED)
		5	GND (BLACK)			5	GND (BLACK)
		6	GND (WHITE)			6	i GND (WHITE)
J13	MONITOR	1	VDD5V	NOT USED			
	5045-4P	2	RX1	NOT USED			
		3	TX1	NOT USED			
		4	GND	NOT USED			
J1 4	SOLITION_VALVE	1	DC24V (WHITE)		SOLUTION VALVE	RED	SOL_VALVE_+
	35313-2P	2	SOLUTION_VALVE(BLACK)			BLUE	SOL_VALVE
J15	VT301_VALVE	1	DC24V		VT-301 SOL_VALVE	GRAY	AIR_VALVE_+
	B3P-VH	2	N.C				
		3	AIR_VALVE			GRAY	AIR_VALVE
J16	DATA_HEAD	1	DC12V (PAR #6 +)		MAIN JP3	1	DC12V (PAIR #6 +)
	D-SUBHD15P(MALE)	2	TX0 (PAIR #2 +)		D-SUBHD15S(FEMALE)	2	2 RX2 (PAR #1 +)
		3	RX0 (PAIR #2 -)			3	5 TX2 (PAIR #1 –)
		4	TX2 (PAIR #1 +)			4	RX0 (PAR #2 +)
		5	RX2 (PAIR #1 -)			5	TX0 (PAIR #2 –)
		6	DC12V (PAIR #6 -)			6	DC12V (PAIR #6 -)
		7	TX1 (PAIR #3 +)			7	RX1 (PAR #3 +)
		8	RX1 (PAIR #3 -)			8	J TX1 (PAIR #3 −)
		9	RD0 (PAIR #8 +)			9	1 RD0 (PAIR #8 +)
		10	GND (PAR #7 +)			10) GND (PAR #7 +)
		11	ENA+ (PAIR #4 +)			11	ENA+ (PAIR #4 +)
		12	ENA- (PAIR #4 -)			12	ENA- (PAIR #4 -)
		13	ENB+ (PAIR #5 +)			13	ENB+ (PAIR #5 +)
		14	ENB- (PAIR #5 -)			14	ENB- (PAIR #5 -)
		15	GND (PAR #7 -)			15	GND (PAR #7 -)

J1 7	PORTA	1	DC24V	NOT USED	SERVO DRIVER CARRIAGE	PIN No3	VDD (RED)	
	5267-12P	2	DC12V	NOT USED	CN1B (3M 20P) 10320	PIN No13	3 VDD (RED)	
		3	VDD5V	NOT USED		PIN No7	SAFETY SIGNAL (WHITE)
		4	PAO	NOT USED		PIN No8	SAFETY SIGNAL (WHITE)
		5	PA1	NOT USED		PIN No20) GND (BLACK)	
		6	PA2	NOT USED				
		7	PA3	NOT USED				
		8	PA4	NOT USED				
		9	PA5	NOT USED				
		10	GND	NOT USED	SERVO DRIVER CARRIAGE			
		11	GND (BLACK) SAFETY SENSOR	GND	CN1B (3M 20P) 10320	PIN No20) GND (BLACK)	
		12	GND	NOT USED				
J18	SOL_ON	1	VDD5V (WHITE)		REFILL J19	1	FOOT_SOL_SW	(BLACK)
	5267-3P	2	N.C		5045-4P	2		
		3	SOL_ON (BLACK)			3		
						4	+5V (WHITE)	
J19	HOME COVER SOL VALVE	1	DC24V		HOME COVER SOL	2	SOL +	
	B2P_VH	2	HOME_COVER_SOL		5559-4 PIN ONLY	4	SOL -	
J20	SPARE_VALVE_2	1	DC24V	NOT USED				
	35313-3	2	N.C	NOT USED				
		3	SPARE_VALVE_2	NOT USED				
J21	SUCTION_VALVE	1	DC24V	NOT USED				
	B4P-VH	2	N.C	NOT USED				
		3	N.C	NOT USED				
		4	SUCTION_VALVE	NOT USED				
J22	SPARE_VALVE_3	1	DC24V	NOT USED	SERVO DRIVER CARRIAGE	PIN No2) GND (BLACK)	(
	5045-2P	2	SPARE_VALVE_3 (WHITE) SAFET	Y SIGNAL	CN1B (3M 20P) 10320	PIN No7	8 SAFETY SIGNAL	_ (WHITE)

J23	MEDIA_SEN_L/R	1 VDD5V (RED)	SAFETY SENSOR PCB	1	VDD5V(RED)
	5267-7P	2 VDD5V	5264-4P	2	N.C
		3 MEDIA_SEN_R (WHITE)		3	SEN OUT(WHITE)
		4 MEDIA_SEN_L (WHITE J23-6과 점퍼)		4	GND (BLACK)
		5 N.C			
		6 GND (WHITE J23-4와 점퍼)			
		7 GND (BLACK)			
J24	HOME COVER	1 VDD5V (RED)	HOME_COVER_OPEN	BROWN	VDD5V (YELLOW)
	5267-6P	2 VDD5V (YELLOW)		BLACK	HOME COVER OPEN (ORANC
		3 HOME_COVER_CLOSE (BROWN)		BLUE	GND (GREEN/YELLOW)
		4 HOME_COVER_OPEN (ORANGE)	HOME_COVER_CLOSE	BROWN	VDD5V (RED)
		5 GND (BLACK)		BLACK	HOME COVER CLOSE (BROV
		6 GND (GREEN/YELLOW)		BLUE	GND (BLACK)
J25	SUB_SOLUTION_2	1 SUB_SOLUTION_2	SUB SOLUTION TANK#2	1	SUB_SOLUTION_2(WHITE)
	5267-2P	2 GND	FLOAT SENSOR 5557-2P	2	GND (BLACK)
J26	AIR_LOW	1 AIR_LOW (WHITE)	AIR_LOW	1	AR_LOW (WHITE)
	35312-2P	2 GND (BLACK)	5557-2P	2	GND (BLACK)
J27	CAPPING/SUCTION PUMP	1 DC24V (RED)	CAPPING MOTOR	RED	MOTOR + (RED)
	35313-4P	2 CAPPING PUMP (BLACK)		BLACK	MOTOR - (BLACK)
		3 DC24V (WHITE)	SUCTION MOTOR	RED	MOTOR + (WHITE)
		4 SUCTION MOTOR (GREEN/YELLOW)		BLACK	MOTOR - (GREEN/YELLOW)
J28	CARRIAGE_422	1 RX+ (ORANGE)	CARRIAGE DIRVER CN3	PIN No9	CARRIAGE RX+ (ORANGE)
	5267-7P	2 RX- (ORANGE BAND)	3M 10320	PIN No1	9 CARRIAGE RX- (ORANGE B
		3 TX+ (GREEN)		PIN No5	CARRIAGE TX+ (GREEN)
		4 TX- (GREEN BAND)		PIN No1	0 CARRIAGE TX- (GREEN BAN
		5 TX- (BROWN)		PIN No1	5 CARRIAGE TX- (BROWN)
		6 GND (BLUE)		PIN No1	1 CARRIAGE GND (BLUE0
		7 GND (BLUE BAND)		PIN No1	CARRIAGE GND (BLUE BAND)

J29	FEED_422	1 RX+ (ORANGE)		FEED DRIVER CN3	PIN No9	FEED RX+ (ORAN	IGE)	
	5267-6P	2 RX- (ORANGE BAND)		3M 10320	PIN No1	9 FEED RX- (ORA	NGE BAND)	
		3 TX+ (GREEN)			PIN No5	FEED TX+ (GREE	N)	
		1 TX- (GREEN BAND)			PIN No1	5 FEED TX- (GRE	EN BAND)	
		5 GND (BLUE)			PIN No1	1 FEED GND (BLL	JE)	
		6 GND (BLUE BAND)			PIN No1	PIN No1 FEED GND (BLUE BAND)		
JP1	COM CHANGE	1 RS232						
	2.54-3P	2 COM	JP1-3과점퍼					
		3 RS424(RS422)	JP1-2와점퍼					

PCB - IF PCB



Main Function

1.Signal Connection at Headbase Lift PCB located on the upper by connecting heater and temperature sensor cable.

Part #; UVI-01

PCB – IF PCB



Part #; UVI-01

CONNECTOR CONNECTION MAP

J1 B6P-VH --> Lift J8 J2 5045-8 --> Lift J7 J3 Disconnection J4 Disconnection J5 B2P-VH --> SMPS#1 DC24V J6 Disconnection J7 B2P-VH --> PID#1-13, PID#2-13 J8 5267-3 --> PID#1-2, 3, 4 J9 B3P-VH --> PID#1-14 J10 5267-4 --> PID#2-2, 3, 4 J11 B2P-VH --> PID#2-14 J12 Disconnection J13 Disconnection







I/F PCB									
J1	B6P-VH	1	DC24V(WHITE)	GORE CABLE	HEAD BASE LIFT PCB	J8	1	SUB_HEATER(BLACK)	
		2	DC24V(GREEN)			B6P-VH	2	BASE_HEATER(BROWN)	
		3	GND(YELLOW)				3	GND(RED)	
		4	GND(RED)				4	GND(YELLOW)	
		5	BASE_HEATER(BROWN)				5	DC24V(GREEN)	
		6	SUB_HEATER				6	DC24V(WHITE)	
J2	5045-8P	1		GORE CABLE	HEAD BASE LIFT PCB	J7	1		
		2	1			5045-9P	2		
		3	BASE B' (ORANGE BAND)				3		
		4	BASE B (ORANGE)				4	SUB A (BLACK)	
		5	BASE A (BROWN BAND)				5	SUB B (RED)	
		6	SUB B' (BROWN)				6	SUB B' (BROWN)	
		7	SUB B (RED)				7	BASE A (BROWN BAND)	
		8	SUB A (BLACK)				8	BASE B (ORANGE)	
							9	BASE B' (ORANGE BAND)	
J5	B2P-VH	1	DC24V(WHITE)		SMPS#1			DC24V	
		2	GND(BLACK)					GND	
.17	B2P-VH	1	DC24V(WHITE)		PID#1-13.PID#2-13				
		2							
J8	5267-3P	1	SUB B' (WHITE)		PID#1-2				
		2	SUB B(WHITE)		PID#1-3				
		3	SUB A(RED)		PID#1-4				
J9	B3P-VH	1	SUB HEATER (BLACK)		PID#1-14				
		2							
		3							
J1 0	5267-4P	1	BASE B' (WHITE)		PID#2-2				
	0207 11	2	BASE B (WHITE)		PID#2-3				
		3							
		4	BASE A (BED)		PID#2-4				
.111	B2P-VH	1	BASE HEATER (BLUE)		PID#2-14				
	SEI VII	2							
		<u> </u>		1	1			1	

PCB - Control PCB



MAIN FUNCTION

1. By connecting with Refill PCB, the current status of refill can be checked, the ink also can be supplied forcefully.

Part #; UVCT-03

PCB - CONTROL PCB



Part #; UVCT-03

CONNECTOR CONNECTION MAP

J18 IDC-30 --> Refill J31 SW2 : LM Manual Refill Button SW3 : LC Manual Refill Button SW4 : Y Manual Refill Button SW5 : M Manual Refill Button SW6 : C Manual Refill Button SW7 : K Manual Refill Button SW8 : S Manual Refill Button D2 : Sub Ink LM D3 : Sub Ink LC D4 : Sub Ink Y D5 : Sub Ink M D6 : Sub Ink C D7 : Sub Ink K D8 : Sub Ink S D10 : Auto Refill LM D11 : Auto Refill LC D12 : Auto Refill Y D13 : Auto Refill M D14 : Auto Refill C D15 : Auto Refill K D16 : Auto Refill K

PCB – CONTROL PCB IO MAP



* Bigger original circuit diagram is attached for understanding.

PCB - CONTROL IO MAP

CONTROL PCB											
J18	1	SW_Y		REFILL PCB	J31	1	SW_Y				
HIF3BA-30PDS	2	SW_M			HIF3BA-30PDA	2	SW_M				
	3	SW_C				3	SW_C				
	4	SW_K				4	SW_K				
	5	SW_LM				5	SW_LM				
	6	SW_LC				6	SW_LC				
	7	SW_W				7	SW_W				
	8	MAUAL_SOL_	SW			8	MAUAL_SO	L_SW			
	9	+5V				9	+5V				
	10	GND				10	GND				
	11	F_LED_Y				11	F_LED_Y				
	12	F_LED_M				12	F_LED_M				
	13	F_LED_C				13	F_LED_C				
	14	F_LED_K				14	F_LED_K				
	15	F_LED_LM				15	F_LED_LM				
	16	F_LED_LC				16	F_LED_LC				
	17	F_LED_W				17	F_LED_W				
	18	F_LED_SOL				18	F_LED_SOL	_			
	19	+5V				19	+5V				
	20	GND				20	GND				
	21	E_LED_Y				21	E_LED_Y				
	22	E_LED_M				22	E_LED_M				
	23	E_LED_C				23	E_LED_C				
	24	E_LED_K				24	E_LED_K				
	25	E_LED_LM				25	E_LED_LM				
	26	E_LED_LC				26	E_LED_LC				
	27	E_LED_W				27	E_LED_W				
	28	E_LED_SOL				28	E_LED_SO				
	29	+24V				29	+24V				
	30	GND				30	GND				



Internet address : www.agfa.com

 HEADQUATERS Agfa-Gevaert N.V.
Septestraat 27
B-2640 Mortsel, Belgium

Tel. +32 3 444 2111 Fax. +32 3 444 7094