Signal Tower Lamp

General POWER "ON"
Flash and Beep if air pressure is under 3.0kg/cm³

INK warning / Low level
Flash and Beep on Low level

UV Lamps "Ready"
Flash and Beep, on Lamp Overheat or Lamp Power Off

Register PINS "Down"
Flash & Beep : Waste Tank Full (> 3.5 litres)

VACUUM in USE

Flash & Beep : All Colors
Over Flow of Ink into Sub Air Tank